

WONDER HC MOV ACTUATOR®



Manual Version	OM-MOV-24-03
Language	English

Please read the manual before use.

After reading the manual, please store it in an easily accessible place for later use. The manual is provided to protect the safety of the installer and user and to prevent damage to property.

OPERATION MANUAL

This page is intended to be blank.

Introduction

This manual provides instructions on:

- Storage and installation of the Wonder HC Actuator[®].
- Manual and Electrical (local and remote) Operation.
- Subsequent commissioning and adjustment of the initial configuration.
- Commission and adjustment of the Control Settings to suit site-specific control and indication requirements.
- Troubleshooting for the Wonder HC Actuator[®].

Before using this product, please thoroughly familiarize yourself with the examples provided in this operation manual.

Please note that this manual was written for products with standard features. The specifications of customized products may vary from the content provided here. Product specifications and contents are subject to change without prior notice, which may result in inaccuracies and incompleteness. Wonder[®] assumes no responsibility or liability for any such situations

If you have any questions regarding the product specifications or any other part, our company and our customer support teams will be happy to assist you.

Wonder Engineering Technologies Pte Ltd

8 Pandan Crescent, #04-01 Singapore 128464 Phone: +65 6656 0181 | +65 6635 6759 Email: <u>support@wonder.com.sg</u> Website: <u>https://www.wonder.com.sg</u>

Confidential Information

The material contained herein consists of information that is the property of Wonder[®] Engineering Technologies and intended solely for use by the purchaser of the equipment described in this manual. All specifications are subject to change without prior notice. Changes are made periodically to the information in this publication, and these changes will be incorporated in new editions.

Wonder[®] Engineering Technologies prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual, without the express written permission of Wonder[®] Engineering Technologies.

Copyright

Copyright © Wonder Engineering Technologies Pte Ltd. All Rights Reserved.

Trademark

Wonder HC Actuator[®] is a trademark of Wonder[®] Engineering Technologies Pte Ltd.

All other trademarks are trademark, registered trademarks, and/or service marks of their respective holders.

Sefety Precautions

To ensure proper use and user safety, and to prevent damage to property, please take note of the following safety precautions before installation:

Precautions for installation

- Follow the manual's instructions during the product installation.
- Adhere to the proper procedure based on the product's weight to ensure safety during transportation and installation.
- If the Wonder HC Actuator[®] cannot be installed immediately, store it in a dry place until you are ready to connect incoming cables.
- When installation of the Wonder HC Actuator[®] is necessary but cabling is delayed, it is recommended to replace the plastic transit cable entry plugs with metal plugs sealed with PTFE tape.
- There is no need to remove any electrical compartment covers for commissioning the Wonder HC Actuator[®].
- The actuator's double-sealed construction will protect internal electrical components if left undisturbed.

Precautions for operation

- Only individuals competent through training or experience should be involved in the installation, maintenance, and repair of the Wonder HC Actuator[®]. Ensure that all work adheres to the instructions in this manual and any other relevant manuals.
- Users and personnel working with this equipment should be familiar with their responsibilities under workplace health and safety regulations.
- Wonder[®] Engineering will not assume any responsibility for on-site deterioration once the covers are removed. Each Wonder HC Actuator[®] undergoes rigorous testing at the factory to ensure years of trouble-free operation when correctly commissioned, installed, and sealed.

WARNING: Motor Temperature

- Under normal operation, the temperature of the HC Actuator's motor cover surfaces can exceed 60°C above the ambient temperature.
- Users must ensure that the operating environment and materials surrounding the HC Actuator do not compromise its safe use or protection.
- Where necessary, users should take steps to protect the HC Actuator against its operating environment.

Content

1	Gene	General				
	1.1	Informa	ation about the user manual	10		
		1.1.1	Legend			
	1.2	Safety		11		
		1.2.1	Explosion Proof Housing			
	1.3	Limit of	f Liability and Warranty			
	1.4	Unpack	king and Inspection			
	1.5	Service	Request, Repair or Support	12		
	1.6	Disposa	al / Decommissioning			
2	Techn	ical Instal	llation —	14		
	2.1	Actuato	or Mounting			
		2.1.1	Rising Stem Valve - Top Mounting			
		2.1.2	Valve with Gearbox - Side Mounting			
		2.1.3	Non-Rising Stem Valve - Top Mounting			
		2.1.4	Hand-wheel Sealing			
		2.1.5	HC-DM Linear Drive Unit	15		
	2.2	Cable (Connection	15		
		2.2.1	Earth/Ground Connection			
		2.2.2	Removing Terminal Cover			
		2.2.3	Replacing Terminal Cover			
3	Settir	na Tool —		16		
	3.1	Setting	a Tool Battery Replacement			
		J	, ,			
4	Oper	ation by H	Hand ————	18		
5	Dical	ny Panal		20		
5	Displa	ay Faller -		20		
6	Oper	ation Guio	de	22		
	6.1	Passwo	ord	22		
		6.1.1	Check Parameter	22		
		6.1.2	Change Parameter			
		6.1.3	Modify Password	23		
		6.1.4	Basic Set	23		
	6.2	Valve Pa	attern	23		
		6.2.1	Close Direction	24		
		6.2.2	Close Mode	24		
		6.2.3	Open Mode	24		
	6.3	Limit Po	osition	25		
		6.3.1	Close Limit Set	25		
		6.3.2	Open Limit Set	26		
		6.3.3	Close Limit Check	26		
		6.3.4	Open Limit Check	26		
	6.4	Torque	Protect	26		
		6.4.1	Close Over Torque	27		
		6.4.2	Open Over Torque	27		
		6.4.3	Strong Torque Allowed	27		
		6.4.4	Torque Close Allowed	28		
		6.4.5	Torque Open Allowed	28		
	6.5	Control	l Set			

	6.5.1	Local Control	-29
		6.5.1.1 Control Mode	30
		6.5.1.2 Local Control Retain	
		6.5.1.3 Position Stop Counter	31
	6.5.2	Remote Control	31
		6.5.2.1 Control Mode	31
		6.5.2.1.1 Manual	32
		6.5.2.1.1.1 Remote Control Retain	32
		6.5.2.1.1.2 Two Line Control	-32
		6.5.2.1.2 Analog	
		6.5.2.1.2.1 Analog Style	33
		6.5.2.1.2.2 Low Signal Adjust	33
		6.5.2.1.2.3 High Signal Adjust	33
		6.5.2.1.2.4 Sampling Average	
		6.5.2.1.2.5 Low Signal liggle	
		652126 High Signal liggle	
		652127 Dead Area	
		6.5.2.1.2.8 Restrain Counter	
		6.5.2.1.2.0 Kestrain Counter	35
		6.5.2.1.2.10 Signal Loss Action Way	
		6.5.2.1.2.10 Signal Loss Action Way	30
		0.3.2.1.3 DUS	
		6.5.2.1.3.1 Bus Mode	36
		6.5.2.1.3.2 Local Address	
		6.5.2.1.3.3 Bus Baud Rate	36
		6.5.2.1.3.4 Control Precision	
		6.5.2.2 Close Valve Jiggle Area	
		6.5.2.3 Open Valve Jiggle Area	
Feedb	back Set		38
7.1	Switch	n Feedback	38
	7.1.1	S1 Set	
	7.1.2	S2 Set	
	7.1.3	S3 Set	
	714	S4 Set	40
	715	Contact Functions	
72	Analo	g Feedback	
1.2	7 2 1	Feedback Allowed	
	7.2.1	Analog Mode	
	722	High Signal	
	7.2.5	Low Signal Adjust	42
	7.2.4	Ligh Signal Adjust	42
	7.2.3	nign signal Aujust	43
Specia	al Set —		44
8.1	IrDA (I	Infrared Kemote Controller) lype	44
8.2	IrDA lı	nhibit	
8.3	Remot	te Interlock	45
8.4	Ir Intei	rlock	-45
8.5	Local I	Interlock	-45
8.6	ESD P	rotect Allowed	46
8.7	ESD V	alid Level	-46
8.8	ESD A	ction Direction	46
8.9	ESD E	xceed Overheat	47
8.10	ESD E	xceed Interlock	47
8.11	ESD E	xceed Local Stop	47

9	Defaul	lt Set	48	
	9.1	First Default	48	
	9.2	Second Default	-49	
	9.3	Third Default		
10	High L	evel Set	50	
	10.1	Position Counter	50	
	10.2	Rating Torque	51	
	10.3	Rating Current		
	10.4	Stall Current	52	
	10.5	Rating Torque/Rating Current/Stall Currrent Setting	52	
11	Alarm	Info	53	
12	Editio	n Info	54	
13	Wiring	g Diagram	55	
	13.1	ESD Wiring Diagram ESD		
	13.2	Interlock Control Wire Diagram	56	
	13.3	2 Wires Control Wire Diagram		
	13.4			
	13.5	4 Wires Control Wire Diagram		
	13.6	Valve Position Transmitter Control Diagram		
	13.7	Valve Torque Transmitter Control Diagram		
	13.8	Remote Analog Signals Control		
	13.9	Remote Analog Signals Control and Switch Control		
	13.10	Remote MODBUS Signals Control and Switch Control	61	
14	Custor	mer Service	62	
15	Mainte	enance	63	
16	Communication			
	16.1	MODBUS Setting		
	16.2	FOUNDATION Fieldbus Parameters Setting		
	16.3	FOUNDATION Fieldbus Configuration		
	16.4			
17	Appen	ndix A: Accessories Lists	113	
18	Apend	dix B: Technical Drawings	114	
19	Index		127	

To ensure consistent document formatting, this page was intentionally left blank.

1.1 Information about the user manual

This manual provides important information that can be used as a work of reference for installing, operating, maintaining, aligning, and/or troubleshooting your Wonder[®] instrument. It is important that you carefully read the information contained in this manual and follow all safety procedures before you install or operate the system. If you are already familiar with this equipment you may to go directly to Section 2.0 Installation Procedure. To avoid handling errors, keep this manual in a location where it will be readily accessible.

This document will be updated with changes as necessary. You are encouraged to recommend and submit changes, additions, and/or corrections to make this document more useful.

1.1.1 Legend

0	Note : Indicated tips and useful information in this manual. All notes should be read to effectively operate this instrument.
Â	Caution : Denotes information critical to avoiding instrument damage or a severe impact to processing. When thiss symbol is found on the instrument it indicates a potential hazard. Consult the documentation before proceeding with any actions.
4	Warming: Denotes information critical to avoiding personal injury, such as when an electrical hazard is present. When this symbol is found on the instrument it indicates a potential hazard. Consult the documentation before proceeding with any actions.
	Protective Earth Ground connection.
4	Cautions Must be Followed: reference supplied documents.
	Electric Shock Hazard: disconnect service before opening.
~	Voltage Alternating Current (VAC)
l==	Voltage Direct Current (VDC).
	Danger: Indicate[s] a hazardous situation which, if not avoided, will result in death or serious injury.

1.2 Safety

This manual provides important information on safety installing and operating your Wonder Instrument. Throughout this manual, you will find various sections containing important safety warnings, indicated by a warning symbol. Regardless of your prior experience with similar instruments or any manufacturer's training, it is imperative that you thoroughly read and understand the contents of this manual before operating the instrument.

It is also important to continually pay attention to all labels and markings on the instrument and to keep the labels and markings in a permanent readable condition.

1.2.1 Explosion-Proof Housing

The housing is designed to meet the explosion-proof requirements of the National Fire Protection Association (NFPA) Article 500 for hazardous locations. This instruments holds the following approvals:

- European ATEX certification
- International IECEX certification

To ensure safe operating conditions, it is recommended that you review the certification and area classifications that pertain to this system.

WARNING



Warning: Hazardous Location Safety Minder – Service personnel shall be qualified to install and service electrical equipment designed for areas classified as hazardous. At no time should the cover be removed unless power is switched off first. When it is necessary to service the instrument with the power applied, ensure the proper safe environmental conditions exist and that such maintenance is authorized and pursuant to safe conditions. See Chapter 15, Safety Assurance and Precautions for more information.

1.3 Limit of Liability and Warranty

All general information and notes for handling, maintaining, and cleaning this instrument are offered according to the best of our knowledge and experience.

Wonder[®] Engineering is not liable for any damages that arise from the use of any examples of the process mentioned in this manual or in case the content of this document should be incomplete or incorrect. Wonder[®] Engineering reserves the right to revise this document and make changes from time to time in the content hereof without obligation to notify any person or persons of such revisions or changes.

All instruments from Wonder[®] Engineering have an effective warranty period. Please check with your respective Sales Representative or email at <u>support@wonder.com.sg</u> for up-to-date warranty information. This warranty covers manufacturing defects and faults which arise during operations, only if there are the results of defects caused by Wonder[®] Engineering Technologies.

1.4 Unpacking and Inspection

Before unpacking the instrument, locate the packing invoice on the outside of the carton. The invoice lists every item that was included in your shipment. Each Wonder[®] Engineering instrument is configured to the default settings. After you have installed the instrument and reviewed the contents of this manual, you will need to configure the instrument to match your application.

When unpacking and inspecting your system, you need to do the following:

- Check all materials in the container against the enclosed packing list.
- Wonder[®] Engineering cannot be responsible for shortages against the packing list unless a claim is immediately filed with the carrier. Final claim and negotiations with the carrier must be completed by the customer.
- Carefully unpack and inspect all components for visible damage.
- Save all packing materials, including the carrier's identification codes, until you have inspected all components and find that there is no obvious or hidden damage.
- Before shipment, each instrument is assembled, calibrated, and tested at the Wonder[®] Factory. If you note any damage or suspect damage, immediately contact the carrier and Wonder[®] Engineering.

Once you have determined the unit you received is the unit you ordered and it is in acceptable condition, the unit is ready for installation.

1.5 Service Request, Repair, or Support

Contact Wonder[®] Engineering Support team in case of a malfunction or service request. Provide clearly stated details of the problem as well as the instrument model number and serial number. Upon receipt of this information, Technical Support will attempt to locate the fault and, if possible, solve the problem over the telephone.

If Technical Support concludes that the instrument must be returned to Wonder® Engineering for repair, they will issue a Return Material Authorization (RMA) number.

Return the instrument upon receipt of the RMA number, transportation prepaid. Clearly indicate the assigned RMA number on the shipping package exterior.

Technical Support can be contacted by telephone or email:

- Telephone: (65) 6686 0181
- Email: <u>support@wonder.com.sg</u>

For customers requiring language assistance, please contact your sales representative to facilitate support and repair.

1.6 Disposal / Decommissioning

Inoperable Wonder[®] instruments must be disposed of in compliance with local regulations for electronic or electronic material.

To ensure consistent document formatting, this page was intentionally left blank.

2 Technical Installation

2.1. Actuator Mounting

2.2.1 Ensure the value is secured before fitting the Electric Actuator as the combination may be top heavy and therefore unstable.

If it is necessary to lift the actuator using mechanical lifting equipment certified slings should be attached as indicated in Fig. 1 for vertical valve shafts and Fig. 2 for horizontal shafts.



Fig 1: for vertical valve shafts



Fig 2: for horizontal shafts

At all times, trained and experienced personnel should ensure safe lifting, particularly when mounting actuators.

WARNING

The HC Actuator should be fully supported until full valve shaft engagement is achieved, and the HC Actuator is securely fastened to the valve flange.

A suitable mounting flange conforming to ISO 5210 or USA Standard MSS SP101 must be attached to the valve. The actuator to valve fixing should adhere to Material Specification ISO Class 8.8, with a yield strength 628 N/mm².

Avoid lifting the HC Actuator and valve combination via the HC Actuator. Always lift the valve/actuator assembly by the valve.

2.1.1 Rising Stem Valve - Top Mounting

A. To assemble the HC Actuator and Base as a combined unit for all actuator sizes, follow these steps:

- Insert the machined drive bush into the thrust base, as described earlier.
- Lower the HC Actuator onto the threaded valve stem.
- Engage the 'hand' and turn the handwheel in the opening direction to secure the drive bush onto the stem.
- Continue turning until the HC Actuator is securely positioned on the valve flange.
- Rotate the handwheel two more turns.
- Attach the securing bolts and tighten them firmly

2.1.2 Fitting Thrust Base to Valve - HC Actuator Sizes 10 to 35 inches only

B. To assemble the HC Actuator and Base as a combined unit for all actuator sizes, follow these steps:

- As previously described, fit the machined drive bush into the thrust base.
- Remove the thrust base from the actuator, and place it on the threaded valve stem with the slotted end of the drive bush facing upward. Turn it in the opening direction to engage the thread. Continue turning until the base is correctly positioned on the valve flange.
- Attach the securing bolts, but do not tighten them at this stage.
- Lower the Actuator onto the thrust base and rotate the complete actuator until the drive dogs on the
- Actuator output shaft engage with the drive bush. The actuator flange should now align flush with the base flange.
- Continue turning the Actuator until the fixing holes align. Use the supplied bolts to secure the actuator to the thrust base and tighten them to the required torque.
- Open the valve by two turns and firmly tighten the fixings onto the valve flange to the required torque.

2.1.2 Valve with Gearbox - Side Mounting

Ensure that the mounting flange is positioned at right angles to the input shaft, and that the drive bush fits the shaft and key with sufficient axial engagement. Engage the 'hand' and position the HC Actuator near the input shaft. Rotate the handwheel to align the keyway and key. Securely tighten the mounting bolts

2.1.3 Non-Rising Stem Valve - Top Mounting

Treat it in a manner similar to side mounting, with one key difference: when thrust is absorbed by the HC Actuator, ensure that a thrust nut is placed above the drive bush and firmly tightened.

2.1.4 Hand-wheel Sealing

Ensure the sealing plug in the center of the hand-wheel (or spindle cover tube, depending on which is fitted) is sealed with PTFE tape and tightened completely to prevent moisture from passing down the center column of the HC Actuator.

2.1.5 HC-DM Linear Drive Unit

The HC-DM type of actuator comprises a lead screw assembly arrangement connected to the base of the actuator, designed to deliver a linear output stroke ranging from a minimum of 8mm (3/8 inch) to a maximum of 120mm (4 3/4 inches). The HC-DM can be provided with or without a yoke mounting adaptor. This adaptor includes four pillars and a base flange tailored to match the valve.

2.2 Cable Connection

Before removing the HC Actuator covers, make sure to isolate all power supplies.

Verify that the supply voltage matches the voltage specified on the HC Actuator nameplate. As part of the wiring installation for the HC Actuator, include a switch or circuit breaker. This switch or circuit breaker should be mounted as close to the HC Actuator as possible and clearly marked to indicate that it serves as the disconnecting device for that specific actuator.

WARNING

Do not use HC Actuators on supply systems with phase-to-phase voltages greater than 600VAC in cases where the supply system is of a floating or earth phase type, and where phase-to-earth voltages exceeding 600VAC could be present.

2.2.1 Earth/Ground Connections

A lug with a 6mm diameter hole is cast adjacent to the conduit entries for attachment of an external protective earthing strap by a nut and bolt. While an internal earth terminal is also available, it should not be used in isolation as the sole protective Earth Connection.

2.2.2 Removing Terminal Cover

Using a 6mm Allen key, evenly loosen the four captive screws. Do not attempt to pry off the cover with a screwdriver, as this can damage the 'O' ring seal and possibly harm the flame path in a certified unit.

Remove the red plastic transit plugs. Prepare the cable entries to match the cable type and size. Ensure that threaded adaptors, cable glands, or conduit connections are securely fastened and fully waterproof. Seal any unused cable entries with a steel or brass threaded plug. Refer to the wiring diagram located inside the terminal cover to identify the functions of the terminals. Verify that the supply voltage matches the voltage marked on the actuator nameplate Remove the power terminal screen. Start by connecting these cables and then replace the screen. Ensure that the wiring diagram is placed back inside the terminal compartment once all connections are complete

2.2.3 Replacing Terminal Cover

Ensure cover "O" ring seal and spigot joint in good condition and lightly greased before re-fitting cover.

3 Setting Tool

The Wonder HC Actuator[®] Setting Tool is a crucial component that facilitates the configuration of Wonder HC Actuator[®] control, indication, and protection functions to align with specific site requirements. It is essential to ensure the compatibility of all actuator settings with the valve, process, and control system requirements before commissioning the Wonder HC Actuator[®].

By using the supplied infrared Setting Tool to access actuator setup procedures, non-intrusive adjustments of torque levels, position limits, and all other control and indication functions can be made efficiently and safely.

Standard diagnostics provide access to information about the control system, valve, and actuator status in the form of display text and help screens. The setup, alarm, and status text is available in English (default), and instantaneous valve torque and position can be conveniently monitored on the actuator with a single key press using the Setting Tool. The onboard Data logger captures operational and valve torque data, enabling informed maintenance decisions.

The Wonder HC Actuator[®] Inside software for PC and PDA allows the interrogation of the Data logger and the complete actuator setup configuration and recording.

Specification

Enclosure	:	IP67
Power supply	:	9V Battery (supplied and fitted)
Operating range	:	0.5m (from actuator display window)

Key	Description
	Up
▼	Down
•	Left
►	Right
٥	Confirm/Enter
-	Decrease
+	Increase
H	Close valve
()]	Open valve
С	Return/Back/Stop



3.1 Setting Tool Battery Replacement

To check the battery status, look at the Infrared transmitter window while pressing any Setting Tool button. A flashing red indicator should be visible. The default battery alarm setting is 30%

When replacing the battery, ensure you are in a safe area. To access the battery, remove the six cap-head screws on the back of the Setting Tool and remove the back cover.

<u>NOTE</u>: When reassembling the cover, make sure the red indicator LED faces the transmitter window in the back cover.

When pressing a button, the Setting Tool transmits instructions to the actuator via infrared pulses. It must be positioned directly in front of the HC Actuator's indicator window and within a distance of 0.5m.

4 Operation by Hand

WARNING: Regarding hand-wheel operation of Wonder HC Actuators[®], it is crucial that no additional lever devices, such as a wheel-key or wrench, be applied to the hand-wheel under any circumstances. Attempting to exert additional force when closing or opening the valve in this manner may result in damage to the valve and/or Actuator, or it could cause the valve to become stuck in the seated or back-seated position.

Push the Hand/Auto lever into the "Hand" position. Turn the hand-wheel to engage the clutch. Release the lever, and it will return to its original position. The hand-wheel will remain engaged until the HC Actuator is operated electrically, at which point it will automatically disengage and return to motor drive. If needed, the Hand/Auto lever can be locked.

Display of Actuator



Operating Electricity

Verify that the power supply voltage matches the voltage specified on the Wonder HC Actuator® nameplate.

Turn on the power supply. It is not necessary to check phase rotation.

Before operating the Wonder HC Actuator[®] electrically, ensure that, at a minimum, the Basic Settings have been configured using the infrared Setting Tool.

Selecting Local/Stop/Remote

• Operation

The red selector allows for either Local or Remote control, and each position can be locked using a padlock with a 6.5mm hasp. Even when the selector is locked in the Local or Remote positions, the Stop facility remains accessible. The selector can also be locked in the Stop position to prevent electrical operation via Local or Remote control.

Local Control

When the red selector is set to Local (anti-clockwise), the adjacent black knob can be turned to select 'Open' or 'Close.' To stop, turn the red knob clockwise.

Remote Control

Rotate the red selector to the Remote position (clockwise) to enable remote control signals for operating the actuator. Local Stop remains accessible by turning the red knob anti-clockwise.

To ensure consistent document formatting, this page was intentionally left blank.

5 Display Panel

Indicator: Serving as a visual signal for displaying the actuator's status, the indicator boasts exceptional visibility in harsh environments. The LED indicator remains clear and recognizable, even during the night and at significant distances.

LCD Interface: The LCD interface is thoughtfully designed to align with users' visual and operational preferences, displaying torque, valve opening, limit settings, and failure alarm information in both textual and graphical formats.



Selection of Control Mode: The selective switch, labeled 'remote,' 'halted,' and 'local,' on the local operating device provides options for remote operation (remote control from Distributed Control System (DCS), local operation (local control), or a halted mode. Local Electric Operation: The operating switch, with 'on' and 'off' settings, on the local operating device allows for easy local opening and closing of the actuator.

5 Display Panel



1. Main Menu

The main menu is categorized into Guide, Setup, Advance, and Information, offering the ability to adjust and configure the actuator's operational parameters.



3. Menu Setup

Users can complete terminal position and torque setting on the LCD interface without the necessity of removing the end cover of actuator.



5. Alarm

Continuous monitoring of environmental conditions and equipment status during operation ensures immediate warnings on the LCD interface for any deviations, like motor overheating.



7. Operating Command

Operating command issued by DCS system can be displayed on the LCD interface. The effective signal will be reversely displayed.



2. Setup Menu

The setup menu allows you to easily view and modify settings such as limits, torque protection, control methods, and feedback methods.



4. Diagnosis

Conveniently inspect the actuator's operating state, operation history, alarm records, as well as its software and hardware versions.



6. Valve Position

Even when observing from long distance, the valve position is still clearly indicated on the large-sized LCD interface.



8. Operating Command

DCS adjustment operating commands and real-time signal values are conveniently displayed on the LCD interface, ensuring precise control.

6 Operation Guide



ELECTRICAL OPERATION MUST NOT BE TAKEN PLACE UNTIL THE BASIC SETTINGS HAVE BEEN MADE AND CHECKED.

The Basic Settings of the Wonder HC Actuator[®] play a crucial role in ensuring the correct operation of the valve. If the Actuator has been provided with the valve, the valve manufacturer or supplier may have already configured these settings. This instruction assumes that the setting mode has been accessed.

6.1 Password

6.1.1 Check Parameter

Point Infrared Setting Tool at the display window of actuator, press Down option key (♥) to check parameter values.

WARNING: At this stage, you do not need to enter the original password, and you cannot modify any parameter values.

6.1.2 Change Parameter

If you want to modify parameter values, press Increase key (+) or Decrease key (-) to enter the original password "08", then press Down option key (∇) to access the Set Menu.

PV: %	
Password: [08]	
Need modify 🕨	
No modify 🔻	

6.1.3 Modify Password

After entering the correct password "08", press Right option key (\blacktriangleright). Then, use the Increase key (+) or Decrease key (-) to select a new password. Press Enter key (\bigcirc) to confirm the new password, then press the Down option key (∇) to access the Set Menu.



6.1.4 Basic Set

Once the Actuator is mounted on the valve, the power supply is on, and Local/Stop control is selected, aim the Infrared Setting Tool at the Actuator's display window from a distance within 0.5m. Refer to the Set Chart to navigate through and display various functions, and their settings will be visible in the LCD window.



6.2 Valve Pattern



6.2.1 Close Direction

- The Electric Actuator can be configured to either close clockwise or anti-clockwise. To establish the correct closing direction, manually operate the actuator and valve. Conversion hand-wheel direction labels are provided for reference
- Use the Increase key (+) or Decrease key (-) to display the character corresponding to the correct closing direction.
- Once the display aligns with the established closing direction, press the Enter key (). The displayed option will flash (stored), indicating that it has been set
- Press the Enter key (**(**) to confirm.



6.2.2 Close Mode

- The Electric Actuator can be configured to close on [torque] for seating valves and [position] for non-seating valves.
- Using Increase key (+) or Decrease key (-), display the required option.



6.2.3 Open Mode

- The Electric Actuator can be configured to open on [torque] for seating valves and [position] for non-seating valves.
- Using Increase key (+) or Decrease key (-), display the required option.





6.3.1 Close Limit Set

- Access the Close Limit Set Menu, use either the hand-wheel or remote controller (close valve or open valve) to adjust the actual close position of the valve. Confirm the adjustment by pressing the Enter key (a).
- When manually adjusting the valve position, the valve position counter value (such as 32768) will change accordingly: it decreases when shaft rolls anti-clockwise and increase when it rolls clockwise.
- The green closing indicator lamp will illuminate, signifying that the close limit position has been set. Press the Right option key (►) to acess the Open Limit Set Menu.



6.3.2 Open Limit Set

- Access the Open Limit Set Menu, and use either the hand-wheel or remote controller (close valve or open valve) to adjust the actual open position of the valve. Confirm the adjustment by pressing the Enter key (4).
- When manually adjusting the valve position, the valve position counter value (such as 33005) will change accordingly: it decreases when the shaft rolls anti-clockwise and increase when it rolls clockwise.
- The red open indicator lamp will illuminate, indicating open limit position has been set. Press the Right option key (►) to access Close Limit Check Menu.

PV:	%
Open Limit	00%
Set	32983
Adjust valve t	to factural open
position	then press
PV:	%
Open Limit	100%
Set	32760
Confirm modi	fy? ►
PV:	%
Open Limit	100%
Set	32760
Set success!	►

6.3.3 Close Limit Check

• After adjusting the valve close limit position, press the Right option key (▶) to verify the close limit value.

PV:	%
Close Limit	32868
Set	(+, -)
After modify	• •

6.3.4 Open Limit Check

• After adjusting the valve open limit position, press the Right option key (▶) to verify the close limit value.

PV:	%
Open Limit	32868
Check	(+, -)
After modify	0 ►

6.4 Torque Protect



6.4.1 Close Over Torque

- This features allows you to set the maximum torque when closing the valve.
- You can adjust the close torque value within the range of 40% to Rated (100%) by using the Increase key (+) or Decrease key (-). If there's no recommended torque value, begin with a low setting and gradually increase it until you achieve satisfactory valve operation.
- When the displayed value flashes (stored), it indicates that the setting has been saved. If the set torque level is reached during closing, the Electric Actuator will torque trip and stop. Confirm the modification by pressing the Enter key ().
- If the Actuator fails to complete a closed valve operation because the set torque is reached, this may indicate a valve and/or process issue or change. It is the user's responsibility to ensure that the valve and process conditions are within specified operational limits before increasing the Set Close torque value.

PV:	%
Close Over	100%
Torque	(+, -)
After modify	● ►

6.4.2 Open Over Torque

- This feature allows you to set the maximum torque when opening the valve.
- You can adjust the open torque value within the range of 40% to Rated (100%) by using the Increase key (+) or Decrease key (-). If there's no recommended torque value, begin with a low setting and gradually increase it until you achieve satisfactory valve operation.
- Confirm the modification by pressing the Enter key (a)
- If the Actuator fails to complete an open valve operation due to reaching the set torque, this may indicate a valve and/or process issue or change. It is the user's responsibility to ensure that the valve and process conditions are within specified operational limits before increasing the Set Open torque value.

PV:	%	
Open Over	100%	
Torque	(+, -)	
After modify	0 Þ	

6.4.3 Strong Torque Allowed

- Unique feature for precise control of valve last 5% stroke is available, this feature is designed for special application; It is usually used in a DCS system for precise control of valve's last 5% stroke to guarantee the flow control.
- Using Increase key (+) or Decrease key (-) to select [ON] or [OFF].

PV:	%
Strong Torque	ON
Allowed	(+, -)
After modify	♥►
PV:	%
Strong Torque	ON
Allowed	(+, -)
After modify	❹►

6.4.4 Torque Close Allowed

- This feature enables the closure of the valve using the torque close mode.
- Using the Increase key (+) or Decrease key (-) to select either [ON] or [OFF].

PV: Torque Close Allowed Torque Protect	% ON (+, -)
PV:	%
Torque Close	ON
Allowed	(+, -)
Torque Protect	♥►

6.4.5 Torque Open Allowed

- This feature enables the closure of the valve using the torque open mode.
- Using Increase key (+) or Decrease key (-) to select either [ON] or [OFF].

PV:	%
Torque Open	ON
Allowed	(+, -)
Torque Protect	❹►
PV:	%
Torque Open	ON
Allowed	(+, -)
Torque Protect	♥►

6.5 Control Set

The Control Set affects how the actuator will respond under conditions of Local Control, Remote Control.



6.5.1 Local Control



6.5.1.1 Control Mode

- This feature allows you to configure the actuator to work in a special mode. Use the Increase key (+) or Decrease key (-) to change the control mode:
- [Default]: Allow operation of the control panel selection and valve on/off [Remote]: Enforces remote control [Stop]: Enforces stop control [Local]: Enforces local control

PV:	%
Control	default
Mode	(+, -)
After modify	❹►
PV:	%
Control	remote
Mode	(+, -)
After modify	❹►
PV:	%
Control	stop
Mode	(+, -)
After modify	♥►
PV:	%
Control	local
Mode	(+, -)
After modify	₽►

6.5.1.2 Local Control Retain

- The default setting for Local Actuator Knob Control is self-maintained [Yes]. If non-maintained actuator knob control is required (jogging, inching, push to run), use the Increase key (+) or Decrease key (-). The display will change to [No]. Confirm the change by pressing Enter key (⁴).
- The displayed option will flash (stored) indicating that it has been set.

When set to [No], only the "open valve" and "close valve" knob should be in their respective positions for the Electric Actuator to function normally. Otherwise, it will stop working.

When set to [Yes], the 'open valve' and 'close valve' knobs will be effective when touched.

PV:	%
Local Control	yes
Retain	(+, -)
After modify	●►
PV:	%
Local Control	no
Retain	(+, -)
After modify	❹►

6.5.1.3 Position Stop Counter

- The setting for the main shaft's stopping and turning can be configured with this feature. The Position Stop
 counter will start counting if the main shaft's status changes from turning to stopping. When the counter reaches
 its upper limit value, it indicates that the main shaft has genuinely stopped working.
- Use the Increase key (+) or Decrease key (-) to adjust the value. The recommended (default) value is 150.

PV:	%
Position Stop	150
Counter	(+, -)
After modify	•

6.5.2 Remote Control



6.5.2.1 Control Mode

- The model of remote control source can be configured as:
 - 1. [Manual]: Indicates remote manual control with on/off type signal.
 - 2. [Analog]: Indicates remote analog control mode (both I/P and O/P are analog signals).
 - 3. [Bus]: Indicates remote bus signal control.
- To access the Manual/Analog/Bus Menu, press the Down option key (▼).

PV:	%
Control	manual
Mode	(+, -)
After modify	❹▼
PV:	%
Control	analog
Mode	(+, -)
After modify	❹▼
PV:	%
Control	bus
Mode	(+, -)
After modify	❹▼

6.5.2.1.1 Manual

6.5.2.1.1.1 Remote Control Retain

- The default setting for Remote Actuator Knob Control is self-maintained [Yes]. If non-maintained actuator knob control is required (jogging, inching, push to run), use the Increase key (+) or Decrease key (-). The display will change to [No]. Confirm the change by pressing the Enter key (^a).
- The displayed option will flash (stored) indicating that it has been set.

When set to [No], only the remote signal should remain effective continuously for the Electric Actuator to work normally. Otherwise, it will stop working.

When set to [Yes] The remote signal will be maintained.

PV:	%
Remote	yes
Control Retain	(+, -)
After modify	❹►
PV:	%
Remote	no
Control Retain	(+, -)
After modify	❹►

6.5.2.1.1.2 Two Line Control

• Configure the operation priority for 2-line Remote Control using the Increase key (+) or Decrease key (-) to change the setting:

[Inhibit]: This feature is disabled;

[Close]: Prioritizes closing the valve.

[Stop]: Prioritizes stopping the valve.

[Open]: Prioritizes opening the valve.

PV:	%
Two Line	inhibit
Control	(+, -)
After modify	₽►
PV:	%
Two Line	close
Control	(+, -)
After modify	●►
PV:	%
Two Line	stop
Control	(+, -)
After modify	❹►
PV:	%
Two Line	open
Control	(+, -)
After modify	●►

6.5.2.1.2 Analog 6.5.2.1.2.1 Analog Style

- Select the style of remote analogue signals: [4-20mA], [0-10mA] and [0-20 mA].
- To choose the desired signal, use the Increase key (+) or Decrease key (-) based on the corresponding code.

PV:	%
Analog	4-20mA
Control	(+, -)
After modify	❹ ►
PV:	%
Analog	0-10mA
Control	(+, -)
After modify	❹►
PV:	%
Analog	0-20mA
Control	(+, -)
After modify	⊉ ►

6.5.2.1.2.2 Low Signal Adjust

- Adjust the value of the low signal by using the Increase key (+) or Decrease key (-) to select a value that corresponds with the LOW set point signal.
- Press the Enter key (^(D)) to confirm.

PV:	%
Low Signal	15%
Adjust	145
Please press e	enter key after
input analog l	ow signal

6.5.2.1.2.3 High Signal Adjust

- Adjust the value of the high signal by using the Increase key (+) or Decrease key (-) to select a value that corresponds with the HIGH set point signal.
- Press the Enter key (^(D)) to confirm.

PV:	%	
Low Signal	73%	
Adjust	730	
Please press enter key after input analog high signal		

6.5.2.1.2.4 Sampling Average

- Sampling average is used for precision control of the analogue signal. To adjust it, use the Increase key (+) or Decrease key (-) to change the value. The range is from 0 to 199, with the default value set at 31.
- Note: Overly precise control may result in a slower response time. The response time is equal to the product of the Sampling average and 10 milliseconds.

PV:	%
Sampling	31
Average	(+, -)
After modify	0 >

6.5.2.1.2.5 Low Signal Jiggle

- This feature allow view and fine-tune the low analog signal sampling value.
- Use the Increase key (+) or Decrease key (-) to adjust the value.

PV:	%
Low Signal	145
Jiggle	(+, -)
After modify	0►

6.5.2.1.2.6 High Signal Jiggle

- This feature allow view and fine-tune the high analog signal sampling value.
- Use the Increase key (+) or Decrease key (-) to adjust the value.

PV:	%
High Signal	145
Jiggle	(+, -)
After modify	❹►

6.5.2.1.2.7 Dead Area

- If the actuator exhibits hunting or unnecessary responses to a fluctuating input signal, consider adjusting the dead area. To achieve more precise control, decrease the dead area, or increase it to reduce hunting. Use the Increase key (+) or Decrease key (-) to select the dead area width.
- The default dead area value is set at 1%.
- When the displayed value flashes (stored), it indicates that the setting has been saved. Confirm the change by pressing the Enter key (@).
- Note: The maximum dead area is 9.9% of the valve stroke. Typically, the minimum dead area should not be set lower than 1%.



6.5.2.1.2.8 Restrain Counter

- This function is used to verify the signal and prevent erroneous operations.
- You can configure the time interval for the Electric Actuator's action, with a range from 0 to 99 seconds. The default value is set at 02.

PV:	%
Restrain	02
Counter	(+, -)
After modify	0 ►

6.5.2.1.2.9 Signal Loss Action

• The default setting is [Allow], which can be changed by using the Increase key (+) or Decrease key (-) to select either [Allow], or [Estop].

PV:	%
Signal Loss	allow
Action	(+, -)
After modify	❹►
PV:	%
Signal Loss	estop
Action	(+, -)
After modify	♥►

6.5.2.1.2.10 Signal Loss Action Way

• [Close], [Stop] and [Open] are available for selection, with the default setting set to [Stop].

PV:	%
Signal Loss	close
Action Way	(+, -)
After modify	₽►
PV:	%
Signal Loss	stop
Action Way	(+, -)
After modify	₽►
PV:	%
Signal Loss	open
Action Way	(+, -)
After modify	❹►

6.5.2.1.3 Bus 6.5.2.1.3.1 Bus mode

• The mode of bus-mastering can be configured as [MODBUS] or [PROFIBUS], with the the default setting set to [Modbus].

PV: Bus Mode After modify	% Modbus (+, -) ❹►
PV: Bus Mode	% Profibus
After modify	(+, -) ❹►

6.5.2.1.3.2 Local Address

• To assign a unique address to the MODBUS module, use the Increase key (+) or Decrease key (-) to display the desired address within the range of 1 to 247.

PV:	%
Local	17
Address	(+, -)
After modify	0 ►

6.5.2.1.3.3 Bus Baud Rate

- Bus Baud Rate can be configured at the following options: 100, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400.
- Note: This feature is only available for [MODBUS].

%
9600
(+, -)
0 Þ

6.5.2.1.3.4 Control Precision

- The control precision option is designed for precise control. When the control mode is set to [<u>Analog</u>], this feature allows to set the allowable error between the target valve position and the current position. The range for this error allowance is from 0.1% to 9.9%. The default value is set at 1%.
- To adjust this value, use the Increase key (+) or Decrease key (-).

PV:		%	
Contro	bl	1.0%	
Precisi	on	(+, -)	
After r	nodify	•	
6.5.2.2 Close Valve Jiggle Area

- The Close valve Jiggle area represents the inertial area for motor operation when it begins to close. When the control mode is set to [Analog], jiggle closing is utilized if the error between the target valve position and the current position falls within the specified limit. Otherwise, the valve is closed normally.
- Use the Increase key (+) or Decrease key (-) to adjust the value of the Close Valve Jiggle Area. The range is from 0% to 99%, with the default value set at 2%.

PV:	%
Close Valve	02%
Jiggle Area	(+, -)
After modify	0V

6.5.2.3 Open Valve Jiggle Area

- The Open valve Jiggle area represents the inertial area for motor operation when it begins to open. When the control mode is set to [Analog], jiggle opening is employed if the error between the target valve position and the current position falls within the specified limit. Otherwise, the valve is opened normally.
- Use the Increase key (+) or Decrease key (-) to adjust the value of the Opem Valve Jiggle Area. The range is from 0% to 99%, with the default value set at 2%.

PV:	%
Open Valve	02%
Jiggle Area	(+, -)
After modify	•

6.5.2.4 Motor Jiggle Counter

- The Motor current-on time can be configured in the Jiggle Area. The default value is set at 60.
- Use the Increase key (+) or Decrease key (-) to adjust the value.
- Each change should be within the range of 1 to 2, and should not exceed 5.

PV	%
Motor Jiaale	60
Counter	(+, -)
32678	$\mathbf{\nabla}$

7 Feedback Set



7.1 Switch Feedback

- There are four contact relays (S1-S4) designed to indicate valve status. Each relay has a passive capacity of 5A/250VAC or 5A/30VDC. These relays can be configured to be pulled in or broken at specific functions (as shown in Section 4.1.5). The contact style can be set as either [normally open] or [normally closed].
- When the Contact function is set to [Any position], the Contact value and Contact range Menu become available for use. The Contact function can be adjusted from 0% to 100% in 1% increments and the Contact range can be adjusted from 0% to 15%.
- S1~S4 relays do not require a power supply, and will retain their last position when power loss occurs.
- Additionally, there is one monitor contact relay (S0) that indicates valve-related issues such as power loss or power off. It has a passive capacity of 8A/250VAC or 8A/30VDC.
- The factory setting for these five contact relays are as follows:

Contact Relay	Contact Function Contact Style	
S1	Full close position	Normally Open
S2	Full open position	Normally Open
S3	Select remote	Normally Open
S4	Colligate alarm	Normally Open
SO	Power fault	Normally Open

- Access the S1 Func Menu.
- Use the Increase key (+) or Decrease key (-) to select [full close position].
- Press Enter key (@) to confirm.
- Press the Left option key (►) to access S1 Style Menu.
- Use the Increase key (+) or Decrease key (-) to select [normally open] option.
- Press the Enter key (@) to confirm.



Only S1 Func being set at [Any position]

7.1.2 S2 Set

- Access the S2 Func Menu by pressing the Down option key (▼).
- Use the Increase key (+) or Decrease key (-) to select [full open position].
- Press Enter key (
) to confirm your selection.
- Press the Left option key (►) to access S2 Style Menu.
- Use the Increase key (+) or Decrease key (-) to select [normally open].
- Press the Enter key (^(D)) to confirm.

PV:	% full anon
S2 Func.	position
After modify	(+, -) ❹►
PV:	%
S2 Style	normally open
After modify	(+, -) ❹ ▼

PV: S2 Value	% 30% (+, -)
After modify	•
Only S2 Func being	set at [Any position]
PV: S2 Range	% 03% (+, -)

Only S2 Func being set at [Any position]

0 🔻

After modify

7.1.3 S3 Set

- Access the S3 Func Menu by pressing the Down option key (▼).
- Use the Increase key (+) or Decrease key (-) to choose [select remote].
- Press the Enter key (*) to confirm.
- Press the Left option key (►) to access S3Style Menu.
- Use the Increase key (+) or Decrease key (-) to select [normally open].
- Press the Enter key (^(D)) to confirm.



Only S3 Func being set at [Any position]

PV:	%
S3 Range	03%
	(+, -)
After modify	• •

Only S3 Func being set at [Any position]

7.1.4 S4 Set

- Access the S4 Func Menu by pressing the Down option key (▼).
- Use the Increase key (+) or Decrease key (-) to select [colligate alarm].
- Press Enter key (^(D)) to confirm.
- Press Left option key (►) to access S4 Style Menu.
- Use the Increase key (+) or Decrease key (-) to select [normally open].
- Press the Enter key (^(D)) to confirm.

PV:	%	
S4 Func.	Colligate Alarm	
A.C. 1.C	(+, -)	
After modify	•	
P\/·	%	
S4 Style	normally open	
0.000	(+, -)	
After modify	• •	
PV:	%	
S4 Value	30%	
	(+, -)	
After modify	• ►	
Only S4 Func being set at [Any position]		
P\/-	%	
S4 Range	/o 03%	
5+ Range	(+, -)	
After modify	• •	
,		

Only S4 Func being set at [Any position]

7.1.5 Contact Function

Any Position	Full close position	Full open position	Close over torque	Open over torque
Start overtime	Any over torque	Close action	Open action	In action
Hand-wheel action	ESD signal	Close interlock	Open interlock	Interlock action
Select stop	Select local	Select remote	Battery lack	Motor over heat
Power loss	Power fault	Actuator alarm	Valve alarm	Colligate alarm

7.2 Analog Feedback

7.2.1 Feedback Allowed

- [Yes] feedback is allowed;
- [No] feedback is not allowed.

PV:	%
Feedback	yes
Allowed	(+, -)
After modify	❹ ►
PV:	%
Feedback	no
Allowed	(+, -)
After modify	❹ ►

7.2.2 Analog Mode

• The style of analog can be configured as [4-20mA], [0-10mA] or [0-10V]. The default setting is [4-20mA], and it is not necessary to modify.

PV:	%
Analog	4-20mA
Mode	(+, -)
After modify	❹►
PV:	%
Analog	0-10mA
Mode	(+, -)
After modify	❹►
PV:	%
Analog	0-10V
Mode	(+, -)
After modify	❹►

7.2.3 High Signal

- [Full open]: High signal (20mA) corresponds 100% open;
- [Full close]: Low signal (4mA) corresponds 100% open.



7.2.4 Low Signal Adjust

- Indicate the low feedback signal. When the valve is in the full close position, the feedback signal should be set to the low signal (4mA).
- Use the Increase key (+) or Decrease key (-) to modify the actual value, and then press the Enter key (@) to confirm.

PV:	%
Low Signal	147
Adjust	(+, -)
After modify	❹►
PV:	%
Low Signal	150
Adjust	(+, -)
Set success!	►

7.2.5 High Signal Adjust

- Indicate the high feedback signal. When the valve is in the full open position, the feedback signal should be set to the high signal (20mA).
- Use the Increase key (+) or Decrease key (-) to modify the actual value, and then press the Enter key (a) to confirm.

PV:	%
High Signal	740
Adjust	(+, -)
After modify	⊈►
PV:	%
High Signal	750
Adjust	(+, -)
Set success!	►

8 Special Set



8.1 IrDA (Infrared Remote Controller) Type

• Use the Increase key (+) or Decrease key (-) to to select [new] or [old], and then press the Enter key (*) to confirm.

PV:	%
Special Set Press @ to ente	► er
PV:	%
IrDa Туре	new (+)
After modify	● ►
PV:	%
IrDa Туре	old
After modify	(+, -) ❹►

8.2 IrDA Inhibit

• Use the Increase key (+) or Decrease key (-) to to select [Yes] or [No], and then press the Enter key (*) to confirm.

PV: IrDa Inhibit After modify	% yes (+, -) ❹►
PV: IrDa Inhibit	% no (+)
After modify	(⊤, -) ❹►

8.3 Remote Interlock

• Use the Increase key (+) or Decrease key (-) to select [Yes] or [No], and then press the Enter key (^(D)) to confirm.

PV:	%
Remote	yes
Interlock	(+, -)
After modify	❹ ►
PV:	%
Remote	no
Interlock	(+, -)
After modify	❹ ►

8.4 Ir Interlock

• Use the Increase key (+) or Decrease key (-) to select [Yes] or [No], and then press the Enter key (^(D)) to confirm.

PV: Ir Interlock After modify	% yes (+, -) ❹ ►
PV: Ir Interlock After modify	% no (+, -) ● ►

8.5 Local Interlock

• Use the Increase key (+) or Decrease key (-) to select [Yes] or [No], and then press the Enter key (^(a)) to confirm.

PV:	%
Local	yes
Interlock	(+, -)
After modify	❹ ►
D\/-	0/
Local	no
Interlock	(+, -)
After modify	❹ ►

8.6 ESD Protect Allowed

- Use the Increase key (+) or Decrease key (-) to select [Yes] or [No], and then press the Enter key (⁴) to confirm.
- Note: Only when ESD Action Direction is set to [Yes], the following functions are effective.

PV:	%
ESD Protect	Yes
Allowed	(+, -)
After modify	♥ ►
PV:	%
ESD Protect	No
Allowed	(+, -)
After modify	❹ ►

8.7 ESD Valid Level

• Use the Increase key (+) or Decrease key (-) to select [High] or [Low], and then press the Enter key (^(D)) to confirm.

PV:	%
ESD Valid	High
Level	(+, -)
After modify	❹ ►
PV:	%
ESD Valid	Low
Level	(+, -)
After modify	❹ ►

8.8 ESD Action Direction

• Use the Increase key (+) or Decrease key (-) to select [Close], [Remain] or [No], and then press the Enter key (^(D)) to confirm.

PV:	%
ESD Action	Close
Direction	(+, -)
After modify	❹ ►
PV:	%
ESD Action	Remain
Direction	(+, -)
After modify	❹ ►
PV:	%
ESD Action	No
Direction	(+, -)
After modify	● ►

8.9 ESD Exceed Overheat

• Use the Increase key (+) or Decrease key (-) to select [Yes] or [No], and then press the Enter key (@) to confirm.

PV:	%
ESD Exceed	Yes
Overheat	(+, -)
After modify	❹ ►
PV:	%
ESD Exceed	No
Overheat	(+, -)
After modify	❹ ►

8.10 ESD Exceed Interlock

- The default setting for ESD Exceed Interlocks is [No]. ESD action will not exceed an active interlock applied to the actuator. If an applied ESD signal is required to exceed active interlocks, causing the ESD action change,follow these steps:
 - 1. Use the Increase key (+) or Decrease key (-) to select [Yes].
 - 2. Press the Enter key (^(D)) to confirm.
- The displayed option will flash (stored), indicating that it has been set.

PV:	%
ESD Exceed	No
Interlock	(+, -)
After modify	❹ ►
PV:	%
ESD Exceed	Yes
Interlock	(+, -)
After modify	❹ ►

8.11 ESD Exceed Local Stop

- The default setting for ESD Exceed Local Stop during an ESD event is [No]. If you want to change this setting, follow these steps:
 - 1. Use the Increase key (+) or Decrease key (-) to select [Yes].
 - 2. Press the Enter key (^(D)) to confirm.
- •

PV:	%
ESD Exceed	No
Local Stop	(+, -)
After modify	❹ ►
PV:	%
ESD Exceed	Yes
Local Stop	(+, -)
After modify	❹ ►

9 Default Set



9.1 First Default

• Factory parameters resume except for Contact relay, Analog input/output, Ir controller type, IrDA inhibit, Bus, High level settings.



9.2 Second Default

• Factory parameters resume except for Contact relay, Analog input/output, Ir controller type, IrDA inhibit, Bus, High level settings (including limit position).

9.3 Third Default

• Factory parameters resume only for Contact relay, Analog input/output, Ir controller type, IrDA inhibit, Bus, High level settings.

10 High Level Set

High level parameters can be configured by this feature.

Note: Select the menu of System reset to restart the Wonder HC Actuator[®]. It's better to deny access to the high level settings.



10.1 Position Counter

• Press the Right option key (►) to enter High Level Set Menu.

PV:	%	
High Level Press O to	Set enter	

• Press the Enter key (@) to enter Position Counter Menu.

PV:	%	
Position	01	
Counter	(+,-)	
After modify	0	

Use the Increase key (+) or Decrease key (-) to change the value from 01 to 03 (24 RPM), 04-05 (48 RPM), 07-08 (96 RPM), then press the Enter key (^(a)) to confirm.

PV: Position Counter Set succeed!	% 03 (+,-)	24 RPM
PV: Position Counter Set succeed!	% 04 (+,-)	48 RPM

PV:	%	
Position	07	
Counter	(+,-)	
Set succeed!		96 RPM

Motor Speed (RPM)	Position Counter Setting
24	2, 3
26	2, 3
48	4, 5
52	4, 5
96	6, 7

10.2 Rating Torque

• Use the Increase key (+) or Decrease key (-) to change the value 5% at a time, then press Enter key (@) to confirm.

PV:	%
High Level Set Press @ to ente	er
PV: Rating Torque After modify	% 40% (+,-)
PV: Rating Torque After modify	% 45% (+,-)

10.3 Rating Current

• Use the Increase key (+) or Decrease key (-) to change the value 5% at a time, then press Enter key (@) to confirm.

PV: Rating Current After modify	% 40% (+,-)
PV: Rating Current After modify	% 45% (+,-)

10.4 Stall Current

• Use the Increase key (+) or Decrease key (-) to change the value 5% at a time, then press the Enter key (@) to confirm.

PV: Stall Current After modify	% 40% (+,-)
PV: Stall Current After modify	% 45% (+,-)

10.5 Rating Torque/ Rating Current/ Stall Current Setting

The default setting for Rating torque and Rating current is around 40~45%. The stall current default setting is around 45~50%. And these three settings were under the high level set.

These 3 data should be set accordingly on site by customer or engineer for commissioning if end-users want this protection function.

Please follow the steps below to set this on site:

- 1. When pipeline is ready, supply the water and let the pump work on its rated head.
- 2. Open the valve by electric actuator and record the sampling value shows on the LCD display.(this sampling value is normally between 200~300.The range is between 0~1000)
- 3. Run the valve from fully close to fully open 2 or 3 times and record the maximum sampling value that you can get.
- 4. Use the remote controller to enter the menu, go to the high-level setting and set the over-current, over-torque and stall current.
- 5. In case, we get the Maximum sampling data are 200, 300, 400 by 3 times operation of the valve. That means 20%, 30%, 40% in high level setting. It is the same logic for the sampling value that you get from the LCD.
- 6. In high level setting menu, for over-current and over-torque setting, we can add 7% on the sampling value for these two settings. i.e. if we get the sampling value is 300, that is to say we get 30%. Then we need set the data as 37% for these new settings. For stall current setting, we need to add another 8%, so we will set the 45% as the stall current setting.

11 Alarm Info

Press the Enter key (^(D)) to view the Alarm Information.

All kinds of alarm signal are as follows:

Signal	Description
Data Error	Error on internal parameter of the actuator
Motor Over Heat	Motor is over-heat
Motor Over Current	Motor is over-current
Open Over Torque	Open torque to the valve is too much
Close Over Torque	Close torque to the valve is too much
Start Over Time	Electric actuator starts over time
Analog Loss	Analog is lost
Power Loss	Shortage of power
Power Fault	Power is failed
ESD Signal	ESD signal is valid
Limit Error	Error on Limit data
Battery Low	Battery power is low

PV:	%	
Edition Info Press Ø to enter		
PV:	%	
Vers: Time:	JFS_V2.6E 11-10-01	

- The feature of "Torque and valve opening percentage constant display on the main interface" (PV: %) is available as an option upon request.
- To navigate through the interface and return to the Sub-Menu at any point, simply press the Return/Back key (C).

13 Wiring Diagram



No.	Description	No.	Description
(E)	Grounding	(22)	Remote Control/ Input for ESD
(1)	3 phase power A/ single phase L1 Line (220V)	(23)	Remote Control/ Input for CL Interlock
(2)	3 phase power B/ single phase N Line (220V)	(24)	Remote Control/ Input for OP Interlock
(3)	3 phase power C	(25)	Remote Control/ Input (common) -ve 20-60VAC/DC
(4)	Internal power source, 24V DC (+)	(26)	Remote Control/common of Input -ve 60-220VAC
(5)	Internal power source, 24V DC (-)	(27)	Mal/ Auto Input -ve 60-220VAC
(6)	Limit Switch S1-1	(28)	Mal/ Auto Input -ve 20-60VAC/DC
(7)	Limit Switch S1-2	(29)	Mal/ Auto Input Control (+)
(8)	Limit Switch S2-1	(30)	Valve Torque Switch CTT (-)
(9)	Limit Switch S2-2	(31)	Valve Torque Transmitter CTT Voltage (+)
(10)	Limit Switch S3-1	(32)	Valve Torque Transmitter CTT Current (+)
(11)	Limit Switch S3-2	(33)	Valve Position Transmitter CPT (-)
(12)	Limit Switch S4-1	(34)	Valve Position Transmitter CPT Voltage (+)
(13)	Limit Switch S4-2	(35)	Valve Position Transmitter CPT Current (+)
(14)	Remote Monitoring Switch S0-1 (N.C)	(36)	24VDC Input (-)
(15)	Remote Monitoring Switch S0-2 (common)	(37)	24VDC Input (+)
(16)	Remote Monitoring Switch S0-3	(38)	Analogue Signal (0~10V, 0~5V) Input (-)
(17)	Remote Control/Input (common) -ve 20-60VAC/DC	(39)	Analogue Signal (0~10V) Input (+)
(18)	Remote Control/Input (common) -ve 60-220VAC	(40)	Analogue Signal (0~5V) Input (+)
(19)	Remote Control for Valve Close	(41)	Analogue Signal (0~20mA, 4~20mA) Input (-)
(20)	Remote Control for Stop/Stay	(42)	Analogue Signal (0~20mA, 4~20mA) Input (+)
(21)	Remote Control for Valve Open	(43)	Cable Shield

13.1 ESD Wire Diagram LED



13.2 Interlock Control Wire Diagram



13.3 2 Wiles Control Wile Diagram



2 wires control by internal power source



2 wires control by external power source

13.4 3 Wires Control Wire Diagram



13.5 4 Wires Control Wire Diagram



13.6 Valve Position Transmitter Control Diagram



13.7 Valve Torque Transmitter Control Diagram



V.T.T using internal power source

V.T.T using external power source

13.8 Remote Analog Signals Control



Remote analog signals control, using internal power source

Remote analog signals control, using external power source

13.9 Remote Analog Signals Control and Switch Control



Remote analog signals control, using internal power source

Remote analog signals control, using external power source

13.10 Remote MODBUS Signals Control and Switch Control



14 Customer Service

Wonder[®] wants to assist you in keeping your instrument online and active. Should you need for service or repair arise, please follow these steps:

- Call (65) 6686 0181 and ask for Customer Service. •
- Explain the problem; we may be able to solve it over the phone. The person handling your call will ask for some • pertinent information to try to determine the nature of the problem.
- If the problem cannot be solved over the phone, the Customer Service/ Sales representative team will schedule ٠ a date and time, and send over our Engineer team for an onsite checking before ask to return the unit to the factory for further inspection.



15 Maintenance

WARNING

Prior to commencing any maintenance procedures, it is imperative to ensure that the main power supply and all other service voltages connected to the terminal board are turned off.

Perform an annual check on your Wonder HC Actuator[®] to ensure its continued proper functioning. Follow these steps:

- 1. Disconnect all electrical power to the actuator.
- 2. Open the electrical enclosure.
- 3. Inspect and tighten all electrical connections.
- 4. Visually inspect the actuator for any electrical or mechanical damage.
- 5. Replace any worn or damaged components.
- 6. If necessary, contact the Wonder[®] Engineering or your local sales representative to schedule an on-site visit by the Services Engineering team.



16 Communication

16.1 MODBUS Setting

16.1.1 Start Delta V Explorer

Drag the controller displayed on the page to the left menu bar.

				- u x
Joint Halp			12 8 10 d 1 a d	
	(1.5) as a plan w 10	the Aston Campbell	21 2 1 K 15 1 K W	
Counses of CITICI.				
Augred Hodde.				
- Mt		Gast (HERSON: 4 (Boscie)	Configue renefits townload non-title	18.07
	Init 196	In the second se	tone tele Contante d' CERCY Autograd Holdet Informant Alama 100 Autograd Holdet Autograd Holdet Informant Alama 100 Autograd Holdet Informant Alama Informant Alama I	A A A A A A A A A A A A A A A A A A A

16.1.2 Set P01 Properties

📓 tepkreij trjitav	24238201		- 0 ×
Carlos (no. Open Contral	- XXXX		·····································
Al Cartano's	Contanto of CEARST		
Al Caltares Detail:	Contents of CEALTY Accognited Problem Processory Aliantes UD Accognited UD	PRI Properties X Port Acharoos Communications Dijantigae Port Hodilad 2002 tijg 28 11 52 08 Hodilad by Element ElEcolord Decoplex Datament	
tie Help, press PE	191	Unit EMERSON 4 (April)	Cellgrenerd3 Doelaal ne-S3 NPI

Manager and Sector		는 표 또
C. C. Mar. 1994 - 1994 - 1994	○ A # # X & 0 0 X 0 0 0 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 1 4 6 0 5 2 3 5 0 0 0 1 4 6 0 5 2 3 5 0 0 0 1 4 6 0 5 2 3 5 2 3 5 0 0 0 0 0 0 0 0 0	R 41 4 40
Al Cintano a	Contents of CTURE	
Column Column	Name Name 100 Image: State Part Advected Extremendation Image: State Part Advected Extremendation Image: State Refer cause Mexcage Second Incl 1 100 Second adjust on state With Extrementation	
Ser Halp, press P3	User (HER)(N + Also)() Config	renewall Doorkadisen 53 WH

CONT.	- A A A A	CONTRACTOR DATES	
Contineers Contracts	Contract of the United Autograd Instance (100 Autograd Autoe (100 Autograd (100	P00 Properties X Put Industrial Communications Proceeding Proceedi	
Ender Ender			



16.1.4 Set the "Dataset Properties"

Al Contrainers	Connects of Villabr			
Cotosta di dinary di System Configuration di Tana	Ansynd Model Urarban Asso 20 Ansered 10			
Control Scoregos Control Scoregos Artis Artis Control Instruction Control Instruction C	Colouri properties General Debail PLC Observices: Debail Meater: 2802 UH 00:10 3(2) Meater: 2802 UH 00:10 3(2)	X [:0-9-4 Hel]1e0.7 E 2:8 405		
w Help, prive F ;		UNITERSON + CONTEC	Configure nen-still Download non-still	18.00

Al Carterers	Contenies of VCL801		
E Cotoffii = 2 Using Inter-Configuration = 2 Salas	Anterprof Notices Autoritize Rama Autoritize Rama	1	
 Control Residução. Control Residução. 	Dataset properties	×	
- <u>-</u> 1912	General Curtain' PLC		
Contract	Detair data tepe 196 Millart vertigate Dotore Tag Chunen Protesten	Fases	
CTLABORETISME		W2 0A 40	
Accepted to Accepted to Accep			
Par tegi, pesa Pi		that 1988 SON + algority)	Colgan un 19 Dariadur-15 R.P.

donaver	Conves of CEAC.		
E tokati E toky Soften Carlovisor E toko	Temphot Produce The Surve Alexes CO decrement No.		
Control Scrimpes Consequence C	Detail properties Denail Datar PLE	×	
Consensational holes	PLC das ype Boot agrees PLC register shar. 3	PLC bare regime address:	
E de tout Chureatorizate		CEA AS SHE	
Anaposition			
Nep presti		Unit D'ERCH 4 danta)	Cardigae tan-Sid Devrivad tan-Sid (K.R.

Containers	Carbon of UTA06'		
Detact Uney Sydex Cellgoride I Mano	Aniges(19tolato) Categories Abino O Do Aniges(10tolato)		
Control To respect Unanged 20 Notements ARCS_A ACCS_A Control National Control National Con	Det suit properties Server (Spaper R)2 Open have Delevel Model 2022 99 00 11:12:54 Model for Evenue Det dectors Det dectors Det dectors Det dectors	× • Coputesclash* • 2.4 802	

d Containers	Codeds of CEAD!		
E betret) E dener Volen Collipsetors + 1 inter	Respired Plat.http: 		
Control to steppe Dranighted 3C Televonces	Dataset properties	×	
Altone Altonomy Altonomy Altonomy Control Manage Altonomy Altonomy	Gameral Datas' PLC PLC data (ym boding mg/mm PLC mg/mm (Find 0	P.Cheeringsterations	
CLURE (DOBROC)		Nei BriA Arg	

16.1.5 Configuration in Control Studio



Remark:

Actuator Status Fedback (two bytes, high byte first)
 B15 B14 B13 B12 B11 B10 B9 B8 B7 B6 B5 B4 B3 B2 B1 B0

B15	Low Battery Level	1: Valid
B14	Power Loss or Phase Loss	1: Valid
B13	Actuator blocked	1: Valid
B12	Off valve over torque	1: Valid
B11	Open valve over torque	1: Valid
B10	Motor overcurrent	1: Active
B9	Motor overheating	1: Active
B8	Internal parameter error of the actuator	1: Valid
B7	ESD operation	1: Valid
B6	Middle position signal	1: Valid
B5	full-open status signal	1: Valid
B4	Closed status signal	1: Active
B3	Actuator is closing	1: Valid
B2	Actuator is opening	1: Valid
B1	Remote Control Operation Status	1: Valid
BO	On-site operating status	1: Active





8 8 C 1	\$V	中間白色と	-	Second Second		(ADA_A: ADA) Cost of Tests		- 3
- 化L	4	Angen Carron China Carron China Chi		15 N 1	1222	10 222		
 PA P	6 1 1 1 1 1 1 1 1 1 1 1 1 1			American Intelligence Calence		NATE REALISTS AUTOLI		and in series and in series (and of a series) of a series of a series of a series (and a series) of a series of a series of a series (b) Series of a series of a series of a series of a series (c) Series of a series of a series of a series of a series (c) Series of a series of
					0		- 10 has	here:
					6			Angele CMA and Direct





16.1.6 Assign the Module

Videor	Survey SULA Survey Survey Cashes 1 to Survey Survey Cashes 1 to Survey Survey Survey SULAR Survey Survey SULAR Survey SULAR Survey Survey SULAR Survey SULAR Survey Survey SULAR Survey SULAR	/ TM				




16.1.7 Download Control Module



16.2 FOUNDATION Fieldbus Parameter Setting

To use analog output to control the HC Actuator, do enable "Do4" first, then adjust the value of "AO01". •

						×.75
NO MEANING MEDI						
a time and the law the					Contraction of the second s	
					IN DADENCA	
					and the second second	A
					Distant Tree	R Parton Strid Merry
					10.00	10
	Contraction of the second	and a second	and the second s		a there	
	Terriport surface 1	Cit opher with Cit Latine	to stop	Analog subjut for actuator	4.80, 80	1
	4.1	E BAL	(AL		N NOT THE	
	And in case of	Sect, Sun	a ladje at the second	a later and	Contraction of the second seco	April 1
	1 million 1	and the second	and the second second	- Do a state	TRACTOR	HE [Per] desy
		Second Second	44	4.0	#1#4	801
	Concernence 1		To change			And Personal Property and
	100 March 100				Dry Permit	ind, below a below
	Sec 12, March 1	- marine	-INA - INA	and a second	10.00	
		1 1 5 mm	MOR.DVCP+	The Course	0.00	Besting Auto-Basel.
	Taken description 1	- T1	the Constant of the Constant	##	Taul I	
	Concerning of the local division of the loca		Townson		Call Contractory	
	da la	- 917			CHELTE FALS	And December Despect
	the statement	No. of Concession, Name	-THAS HIT-	and a second second	184631438, (5470)	And defended in the last
	- Inconstitution	1000	BURLING & S	BOOK DOT N	The COLOR AND A	A COLORADO COLORADO
		No. 20 CO	87	**	THE REPORT OF	
			Enable Analog output		8,00	4
	- M.C	- are	10.0	The second secon	H.J.	
	and a second	the T Street	BOR BOARD	and the second second	18:264	1
		40			# 12", 314-5	
				P-0.1	1.00	5 · · · · · ·
					0011.1000	1
					18164	
					and the second s	
					3,975	
					10000	Sheered 1
					1.778	Direct .
					(UR) IN	*
					a constant	
					Column .	And Belleville Belleville
					1448	1.2.5
					Carl Control Street	highlighted and
					Walk Park	Ret Reported
					tim star	APDING BUILD
					ALL	
					di tence anno -	20/27/14
					10x 20x 21x10	Rear to all cards
					The has	The set is up and
					and the second of the second o	
						12.000

- Please refer to the following table for the control command.
- For DI block, the value needs to convert to binary type to indicate the HC Actuator status. For example, if "OUT-• _D Value" = 156, which is 1 0 0 1 1 0 0".

	BITO	BIT1	BIT2	BIT3	BIT4	BIT5	BIT6	BIT7
DI 1	Fully Closed	Fully Open	Analog Enable	Remote	Common Alarm	Moving	ESD Valid	50% Position
DI 2	Fully Open	50% Position	Fully Closed	Analog Enable	Common Alarm	Moving	Remote Mode	ESD Valid
DI 3	Common Alarm	Fully Open	50% Position	Fully Cosed	Analog Enable	Moving	Remote Mode	ESD Valid
DI 4	Analog Enable	Common Alarm	Fully Open	50% Position	Fully Closed	Moving	Remote Mode	ESD Valid

	1	0	0	1	1	1	0	0
--	---	---	---	---	---	---	---	---



• Field Command:



A. DO 1 - Wonder HC Actuator[®] Stop:

- 1. Click on the DO1 module.
- 2. In the MODE_In BLK section, click on "Actual," and change the status to "Auto" from the drop-down options.
- 3. Ensure that when testing the "DO 1 -- DO 3" module, it remains in the "Auto" status.
- 4. In the SP_D VALUE section, change "Discrete State 0" to "Discrete State 1" from the drop-down box.
- 5. Download or save the configuration.
- 6. As a result of these changes, the Wonder HC Actuator[®] is expected to stop.

Monitor		Ψ×
目指指人参查到①辛		
Object Name	DI_1	
Object Type	H1 Function Block Reference	- 11
VIX_T2	4	-11
TAG_DESC		
STRATEGY	0	
ALERT_XEY	0	
B HORE NUX		
TARGET	Anto	
ACTUAL.	Auto	-11
PERMITTED	DGS Man Auto	-11
HUSWAL	Auto	
LOCK SER	3233.02v	-11
CITY 1		ed i
STATUS	Good Repformate Repform for Rolling	
Value	156	
A DET. 3		-1
Cettain:	Good RecConnels : RecConnilia Notice	
NUMP	100	-
VALUE	130	- 1
CITER CALIFIC CALIFIC		
SINULATE_STATUS	Good FinCascada . Bonopacitic BotLon.	
SIMULATE_VALUE	196	• 11
TRAESDICER_STATICS	Good HenCascade WonSpecific MetLin	
TRANSDUCER_VALUE	156	_
EMABLE_DISABLE	Disebled	
ID_STATE	0	
DUT_STATE	0	_11
GRANT_BENT		
GRANT		
DENT		
IO_OPTS		
STATUS_OPTS		
CHARGEL	Chatael 1	
TV_FTIME	0	
B YIXLD_YAL_D		
STATIS	Good_NenCatende: NonSpecific:NotLin	
VALUE	196	
UFBATE AVT		
UNACIONNEEDGED	Unacknowledged	
UPDATE STATE	Not Reported	
TIME STAMP	1972/01/01 03:02	
STATIC REVESION	4	-11
BELATIVE INDEX	0	-11
B BLOCK ALS		-
INACIONAL PLOPE	Univitial isad	
ALARM STATE	Universitational	-11
TTHE CTARS	1972/01/01 03:02	-11
218 (1159	DetOFfarm ca	-11
Unit see	0	-11
D af ann Tim	0.000	nd.
0.00107	Discussion (1) and	
LINE CONTRACTOR	Discrete Alere	
034.3009123923	DISC ADS USACR	
CONCEPCIENCE.		
DISABLED		
ACE_OPTIOS	V get	
IISC_FRI	0	
DISC_LIM	0	



B. DO 2 - Wonder HC Actuator® Close:

- 1. Click on the DO2 module block.
- 2. In the SP_D VALUE section, select "Discrete State 1" from the drop-down options.
- 3. Download the configuration.
- 4. As a result of these changes, the Wonder HC Actuator[®] shall close.
- 5. After performing the intended action, set the Discrete value back to 0.

Monitor		ąχ
目影影奏奏长到①《	2	
Object Name	10_2	
Object Type	HI Function Block Reference	- m
ST_REV	4	
TAG DESC		
STRATEGY	0	
ALERT_KEY	0	
BODK_BLK		
TARGET	Auto	
ACTUAL	Auto	
PERMITTED	OOS Man Auto Cas RCas	
NORMAL	Auto Cas	
BLOCK_ERR		
B PV_D		
STATUS	Good_Cascade: :NotInvited:NotLinited	
VALUE	0	
E SP_D		
STATUS	Good_Cascade::NotInvited:NotLimited	
VALUE	Discrete state O	_
E cai b		
STATUS	Good_Cascade: :NotInvited:NotLimited	- 10
VALUE	0	
E SIMULATE D		
SIMULATE_STATUS	Good_Cascade: :NotInvited:NotLimited	- 11
SIMULATE_VALUE	Discrete state O	1
TRANSDUCER_STATUS	Good_CascadeNotInvited.NotLimited	
THANSDUCER_VALUE	Discrete state O	- 11
ERABLE_DISABLE	Disabled	- 11
PV_STATE	0	- 11
AD_STATE	0	
E GRANT_DENI		-
GRANT		- 11
DENI TO OTTO		- 11
10_0F15		- 11
STRIUS_OFTS		- 10
CTATIC CTATIC	Good Corneds : NotTerrited NotLinited	
VALUE	Discrete state 0	-11
C CAS TH D	DISCHAGE SCACE O	- 10
CTATIC CTATIC	Rad WenSpecific WetLinited	
VALUE	Discrete state 0	-10
CHANNEL	Channel 2	-10
COURSEL .	CONDITION 2	-
PETATE VAL D	0	
D DIGAL OF D	v	



C. DO 3 - Valve Open:

- 1. Click on the DO3 module.
- 2. In the SP_D VALUE section, change it from "0" to "1".
- 3. Download the configuration.
- 4. As a result of these changes, the Wonder HC Actuator® shall open.
- 5. Download or save the configuration.
- 6. As a result of these changes, the Wonder HC Actuator® is expected to stop.

Monitor		аx
□ \$\overline\$ \$\dots\$ \$\dots\$ \$\dots\$ \$\overline\$ \$\dots\$ \$\dots\$ \$\overline\$ \$\overli		
Object Name	DO 3	
Object Type	HI Function Block Reference	- m
ST REV	4	
TAG DESC		
STRATEGY	0	
ALERT KET	0	
O NODE BLK		
TARGET	Auto	
ACTUAL	Auto	
PERMITTED	00S Man Auto Cas BCas	
NORMAL.	Auto Cas	
BLOCK ERR		
E PV D		
STATUS	Good Cascade: :NotInvited:NotLimited	
VALUE	0	
E SP D		
STATUS	Good Cascade: :NotInvited:NotLimited	
VALUE	Discrete state 0	
E OUT D		
STATUS	Good_Cascade::NotInvited:NotLimited	
VALUE	0	
B SINVLATE_D		
SIMULATE_STATUS	Good_Cascade: :NotInvited:NotLimited	
SINULATE_VALUE	Discrete state O	E
TRANSDUCER_STATUS	Good_Cascade: :NotInvited:NotLimited	11
TRANSDUCER_VALUE	Discrete state O	
ENABLE_DISABLE	Disabled	
PV_STATE	0	
XD_STATE	0	
GRANT_DENT		
GRANT		
DENY		
IO_OPIS		
STATUS_OPTS		
E READBACK_D		
STATUS	Good_Cascade: .NotInvited.NotLimited	
VALUE	Discrete state O	
CAS_IN_D		
STATUS	Bad: NonSpecific:NotLimited	
VALUE	Discrete state O	
CHARNEL	Channel 3	
YSTATE_TIME	U	
FSTATE_VAL_D	0	
BKCAL_OUT_D		
STATUS	Good_Cascade: NotInvited.NotLimited	
VALUE:	Discrate state 0	

D. DO 2 - Enable AO Control:

- 1. Select the DO4 module.
- 2. Click on SP_D VALUE.
- 3. Change the Discrete State from 0 to 1.
- 4. Download the configuration.

<u>NOTE</u>: Ensure that DO4 is set to "<u>1</u>" for <u>Analog</u> Control. (If DO4 is set to "<u>0</u>," it is in <u>ON/OFF</u> control mode).

Monitor		1.5
目影影人参至此〇章	ŧ.	
Object Name	10.4	ī,
Object Type	HI Function Block Reference	h
ST_REV	4	11
TAG_BESC		11
STRATEGE	0	11
ALERT_XEY	0	н
B 8002_NLX		
TANGET	Auto	11
ACTUAL	Anto	11
PERMITTED	005 Man Auto Cas BCas	11
NCEMAL.	Auto Cas	1
BLOCK_RRR		Н
□ 2 ¥_3		
STATUS	Good_Currada: :NotInvited NotLi	11
VAEME	1	Н
B 57_3		
STATIES	Good_Canzada : NotInvited NotLi	1
VALUE	Discrete state 1	
a our_1		•
STATUS	Good_Cascade: :NotInvited:NotLi	Н
VALVE	1	11
E SINVLATE_D		
SIMULATE_STATUS	Good_Cascade NotInvited NotLi	11
SIMULATE_VALUE	Discrete state 1	12
TRANSDUCER_STATUS	Good_Cancade: NotEnvited NotLi.	11
TEAMSDUCER_VALUE	Discrete state 1	1
ENABLE DISABLE	Disabled	Н
PV_STATE	0	11
XD_STATE	0	11
CLANT_DENT		
GEANT		11
DENT		Н
IO_OPTS		11
STATIS_OPTS		11
E READBACK D		
STATUS	Good_Cascada: NotInvited NotLi	11
VALNE	Discrete state 1	Н
CAS_IN_N		
STATUS	Bad: :NonSpecific:NotLimited	11
VALUE	Discrete state 0	1
CHANGEL	Changel 4	
PSTATE_TIME	0	Н
PSTATE_VAL_D	0	1
BREAL OWT 1		
STATUS	Good_Cascade: NotInvited NotLi	1
VALVE	Discrete state I	1
E RCAS_IN_N		F
STATUS	Bad : MonSpecific NotLimited	
VALUE	Biscrete state 0	
SHED_00T	Uninitialized	
B RCAS_OUT_B		
STATUS	Good_Cascade: NotInvited NotLi	
VALUE	Discrete state 1	
UPDATE XVT		
UNACIDIOWLEDGED	Unacknowl edged	
IFDATE_STATE	Not Reported	
		1.7

E. Analog Control WONDER HC Actuator:

- 1. Click on the AO1 module.
- 2. In the MODE_In BLK section, click on Actual and change the status to "OOS".
- 3. In the PV_SCALE & XD_SCALE option:
 - Set the EU (Engineering Units) value to "100."
 - Change the DECIMAL value to "0."
 - Change the UNITS symbol of INDEX to "%."
- 4. Back in the MODE_In BLK section, click on Actual and change the status to "Auto".
- 5. In the SP (Set Point) section, modify the required valve position value in VALUE, such as "50."
- 6. Download the configuration.
- 7. The Wonder HC Actuator® should open to the desired position as set, 50%

Monitor		8 X
日告告本会有其①存		
Object Range	10.1	12
Object June	10. Function Dock Reference	- 6
ST MEY	6	-11
TAG DESC		-11
STRATEGY	0	-11
ALERT NEV	0	
B BOOK BLK		
TABGET	Anto	
ACTUAL.	Ante	
PERMITTED	005 Wan Auto Can BCan	
HORMAL.	Auto Cas	
FLOCK ENR		
G 17		
STATUS	Good MonCascade SonSpecific NotLin.	
VALUE	50	
B \$7		
STATUS	Good Cancada: :RonSpacific:RotLinited	
VALUE	50	
1997		
STATUS	Good Cancada : NotInvitad BotLimited	
VALUE	50	18
C STHULATE		
SINULATE STATUS	3ad OutOffervice SotLinited	
SINULATE VALUE	Ô	
TRANSPICZE STATUS	3nd: DutOffervice NotLimited	
TRANSDUCER VALUE	0	
ENABLE DISADLE	Zizablad	1
TA SCALL	- Second second	
E0_100	100	
EV_O	0	
UNITS_INDEX	\$	
IECEMAL	0	
C TR SCALE		
10 100	100	
EV_0	0	
UNCES_INDEX	1	
DECEMAL.	0	
E GRANT RENT		-
GRAST		
1891		
IO_OFTS		
STATUS_OPES		
C READEACE		
STATUS	Good_Cancade NotInvited BotLimited	
VALUE	50	
CAS_IN		
STATUS	Bud: BerSpacific BatLinited	
VALUE	0	
SP_RATE_DS	1. #1#7	
ST_BATE_UP	1.4089	
NILIN SP. NILIN	100	
57_L0_LIM	0	
CHARGEL	Charael 1	
PSTATE_TIRE	0	
PSTATE_VAL	0	
G BELAL DET		
State Little And	is an anne in an anna in	-
and the second se	Caps Num	Scrall

For Wonder HC Actuator[®] FF setting in DCS, the typical communication configuration are as follows:
 Select "17_MTB6001" on the left, and then click any parameter on the right.

1000 10000 1000	Exc. area								-		OIC MA
Constraint Constra	SHE BACK CHERNI BRO	6								_	
NUM NUM <th>(A. (A. 2 2) 101</th> <th></th>	(A. (A. 2 2) 101										
NUMB Classifier Status Viewer Distribution Status Distribution Status Distribution Status Distribution Status Distribution Status Distribution Status Distribution Distributio	C C B B C B	W. M. MI.									
Number Company Company <th< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th>2012/07/17</th><th>ALC: UNK</th><th>and the</th><th>MACTO</th></th<>								2012/07/17	ALC: UNK	and the	MACTO
Notice Notice<	NO. DO	118.00 A 118.82	5758	VENELTER	10.011	1882	101	202518	1554	HENR	ROSCHIE!
Control Control <t< td=""><td>A GALERANCE</td><td>10,42V HL #2018</td><td></td><td>ABVEVA.</td><td>Einteinel</td><td>Life" of Boles</td><td></td><td>88</td><td>habitine.</td><td>323.464</td><td>3115-65-14</td></t<>	A GALERANCE	10,42V HL #2018		ABVEVA.	Einteinel	Life" of Boles		88	habitine.	323.464	3115-65-14
Note: Note: <th< td=""><td>- M rodevou</td><td>THILDRIC INC ADDEB</td><td></td><td>Figures</td><td>Contained .</td><td>Chief String</td><td></td><td>04/08</td><td>Meridan.</td><td>305481</td><td>311446-14</td></th<>	- M rodevou	THILDRIC INC ADDEB		Figures	Contained .	Chief String		04/08	Meridan.	305481	311446-14
Number Number Participant Paritipant Paritipant Parit	A B PORT	CRA/SUT HS #SING		#Exam.	Contained	UNT Disten		100.114	deninger.	2014-08-1.	210100-08
Witch, If Witch, If <t< td=""><td>a particular second</td><td>REAL PROPERTY.</td><td></td><td>7404947</td><td>Contained.</td><td>UNF S Ave:</td><td></td><td>108.574</td><td>Advisor.</td><td>2012-00-1</td><td>2010-00-19</td></t<>	a particular second	REAL PROPERTY.		7404947	Contained.	UNF S Ave:		108.574	Advisor.	2012-00-1	2010-00-19
Interview Description Description <thdescription< th=""> <thdescription< th=""> <</thdescription<></thdescription<>		NUMBER OF STREET		210700101010	transferred / Can.	Anosh Tant			Advente-	351.061	30346-04
Contract Provide ProveProvide ProveProvide Provide Provide Provide Provide Provide Pro	In an and an	Succura H same		2 cmm/r/frei	dynamic (ritera).	10 Billions	Dates, 10	108	Mental-	Storest.	210446-18
Project Notice with Heads Projection Projection Notice with Heads Projection Notice with Heads Distribution Distribution <thdistribution< th=""> Distribution</thdistribution<>	C ALT MUT AND A	Burbatkyov in addisa		Parme	Operation (Garral-	Name Type			advision-	2010061	2034618
P James R MARINE, wit #ERR# L Constant Dual (MT M) P Marine Difference Difference <td>17 X 19 X 19 X 1</td> <td>BUDDY, KAN HE +BITE</td> <td></td> <td>PECENT</td> <td>Operatio, Harriel.</td> <td>Receive Topic</td> <td></td> <td></td> <td>Advision-</td> <td>2014/051-</td> <td>2010/06/18</td>	17 X 19 X 19 X 1	BUDDY, KAN HE +BITE		PECENT	Operatio, Harriel.	Receive Topic			Advision-	2014/051-	2010/06/18
1 (1) 1 (1)	17 Amos	TANDAG. N. PRIME		L	Gentariad	Search (1897) (6.8	Dandard Frenza	110	hitrian-	3001491-	3010449-04
Image: second	TT AMAGE	NUMBER OF STREETS		2406003044	Balantic / Contral.	Teast (1097-81)	improduct and	114	adviser.	301/-661	20140-10
Vision Vision<	17 A11400	Children, Hamma		100 COLOR 1	Sanita J Conshi.	Search With a line	few sensor and -	108/006	Advision.	314461	2134618
Image: processing in procesing in procesing in processing in processing in processing in pr	17 201400	States			installed .	Bears (siller \$1	Access (10	CR .	identity.	1010-06-1-	21545.00
E f allite W 00 gifs N 00 gifs <	T 471280	B MURANE IN PRIME		1 C	Gampined	Investigative au	240.00	106.476	Advisit.	1010491.	201446-14
If Actions If Mathematical State If Description If Actions	- T,alt100	Contraris we wanter		1.0	Compiled	Investiged at	D-4 Imp (0.0)	108.474	identer.	101446-1-	1014-05-10
If Second Constant	17,A05400	R PARTY IN ARTIS		5	dustgined	from (10NT E)	Now 12	18.54	haven.	1015-66 L.	1711-05-18
Image: constraint of the state of	17,045win	CRE,CACOL HC #BITUR		1	Contained	Dist CUNT \$1	Normal CO.	08/016	Marine.	215464.	2110-00-18
Image: state of the s	- 🗶 (7 (pisen))	THE OUT HE HERE		1.5	Consend .	LOW LT MONEY		106.178	here's	1016-04 L	8144614
E 10 ACMAND	- E 17,00,000	NAMES. IC POINT		1.0	Listigned .	LOW COMP		100.119	identical.	201491	1010-00-08
If Discourse If Discourse<	- E 17,00000	Standary, House		E. Contents	Casteland	darias Talat			Address.	1011-00-1.	10101-00108
If (Journey) If (Journey)<	- E 17,000490	ALL MARKS HE MARKS		210000000	Contained	12 Million	8400.048.00	104	Million-	2014-00-1	20102-00110
EXPLOSIVE	1 2,000000	MIRLOOK, HI MAND		L	Consistent	feart (UNTR)	MOD, INC US	10000	Revision-	210.041	1010-08-18
E 17 20000 E 17 20000 E 17 2000	Th DODAR	Binkacik, w esta		2 coloristications	Greated	International Property and	CR-01	Die .	idei-im-	214441.	214.66.76
E 17 POLICE E 17	17,000000	MINIO INL INC MINING		2 (0)(0)(2)(0)	Duramic / Cantal.	Revealer Trave			Advision-	214-06-1	2144918
Constant	2 17 (MDUX)88	CALLOC. IL BRIDE			Gamping	Reside Taper			Advance.	2010-001	210.00.00
E DE CARLON, MI BERTE 4 Cursinel Acode Type Adoles, Blobba, Bl	2 (r.mount)	MOD INC INC METH		2-08-01/01/02	Bananie / Gorbal,	Records Type!			Advision .	1010-001	1014-00-10
a the constant of a second sec	C 980000	RAUNC. HINKS			Garained	Autoide Paper			iddian.	IDAME.	BUDDED.
	Trietown	Station in all states		Long-rays	Renamin J (social.)	Animik Paper			44-1-1-	1010-00-1	101.0 mm (m
	1 10 10 10 10 10				1.000						Contraction of the
		11.									or many low

- 2. (I) Select "MODE_BLK ".
 - (II) Set the "TARGET" parameter to "OOS" mode only (it needs have to be set to "OOS" mode in order to change the parameter),
 - (III) Once the "TARGET" parameter is in "OOS" mode, proceed to make the desired parameter settings and configurations.
 - (IV) Once all settings are configured, enter the running state.
 - (V) Set the "TARGET" parameter back to "Auto" mode.
 - (VI) Save all the parameter adjustments, including any FF (Foundation Fieldbus) Modbus configurations, to retain your settings.
 - (VII) With the configurations saved, you can initiate FF communication, allowing the actuator to communicate and function based on the new settings.

ALL	1	目的的的影		
TUTTUT		整故名称	MODE_BLX	
CONTAINED	11	参数类型	Recode Type	
ST_REV	1.00	E TANGNT		
TAG_DESC		封掘実型	0 Dit Eros	
STRATEGY		TANGET	Asta	
ALERT_KEY		EI ACTUAL		
WOOK BLK		約据共型	O Est. Error	
BLOOK_ERR		ACTURE.	Anto	
UPDATE_EVT		C PROMITIN		
BLOOK_ALM		約据类型	8 Bit Enw	
TRANSDUCER_TYPE		PERMITTED	OOS Auto	
XD_ERROR.		S NURRAL		
SENSOR_TIPE		数据类型	0 Dit Erus	
MEDIA		NORMAL.	Anto	
BAUD_RATE				
STOP_BITS	-			

3. FF - Internal MODBUS Communication Port Setting:

BAUD RATE:	9600
STOP_BITS:	One Stop Bit
PARITY:	None
NUMBER_OF_RETRY:	1
SLAVE_DEVICE_ADDRESS:	17/17/17/17

4. FF - Module Block Configuration

Module Block Name	Description	Setting
Al1	/*Actuator torque value*/	SCALE_LOC_IN1 DATA_TYPE:Float_3210 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:100 REGISTER_ADDR_OF_STATUS:0
AI2	/*Actuator torque value*/	SCALE_LOC_IN2 DATA_TYPE:Float_3210 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:100 REGISTER_ADDR_OF_STATUS:0
AI3	/*Actuator value position percentage*/	SCALE_LOC_IN3 DATA_TYPE:Float_3210 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:104 REGISTER_ADDR_OF_STATUS:0
Al4	/*Actuator value position percentage*/	SCALE_LOC_IN4 DATA_TYPE:Float_3210 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:104 REGISTER_ADDR_OF_STATUS:0
AO1	/*Actuator opening adjustment*/	SCALE_LOC_OUT1 DATA_TYPE:Float_3210 Function_Code:FC16 REGISTER_ADDR_OF_VALUE:108 REGISTER_ADDR_OF_STATUS:0 Add: FROM-EU100 current value 100, TO-EU100 current value 100
DI1	/*Alarm and status 8-bit DI1*/	SCALE_IN_D1 DATA_TYPE:Usigned8_0 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:2 REGISTER_ADDR_OF_STATUS:0
DI2	/*Alarm and status 8-bit DI2*/	SCALE_IN_D2 DATA_TYPE:Usigned8_0 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:3 REGISTER_ADDR_OF_STATUS:0

Module Block Name	Description	Setting
DI3	/*Alarm and status 8-bit DI3*/	SCALE_IN_D3 DATA_TYPE:Usigned8_0 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:4 REGISTER_ADDR_OF_STATUS:0
DI4	/*Alarm and status 8-bit DI4*/	SCALE_IN_D4 DATA_TYPE:Usigned8_0 Function_Code:FC04 REGISTER_ADDR_OF_VALUE:5 REGISTER_ADDR_OF_STATUS:0
DO1	/*DO1 - Stop*/	LOC_Out_D1 DATA_TYPE:Usigned8_0 Function_Code:FC05 REGISTER_ADDR_OF_VALUE:0 REGISTER_ADDR_OF_STATUS:0
DO2	/*DO2 valve closing*/	LOC_Out_D2 DATA_TYPE:Usigned8_0 Function_Code:FC05 REGISTER_ADDR_OF_VALUE:1 REGISTER_ADDR_OF_STATUS:0
DO3	/*DO3 valve opening*/	LOC_Out_D3 DATA_TYPE:Usigned8_0 Function_Code:FC05 REGISTER_ADDR_OF_VALUE:2 REGISTER_ADDR_OF_STATUS:0
DO4	/*DO4 regulation enable*/	LOC_Out_D4 DATA_TYPE:Usigned8_0 Function_Code:FC05 REGISTER_ADDR_OF_VALUE:3 REGISTER_ADDR_OF_STATUS:0

16.3 FOUNDATION Fieldbus Configuration Based on Yokogawa DCS System Centum VP R6.09

	# # 5	Contraction Amounts			2	A - Downson and a lot of the lot	VOICOANA D
	100 AD AD	C Concept	100 C	00.0 t 000 1	factorse	te	12
Image: Section 2000 P Image: Section 2000 P					Hartore Receive Internet Inte		12 mmonth 12 mmo
							la la

1. Ensure that the DD file (from manufacturer) is installed in the fieldbus destination before registering the device.

No and antice	N THE	NAME MARKS	M			
e deviar		1 List Device Lie	Common Telfarmati	164]		
	10	Dermital Bumper	Dative Lot some	BUDGE THE BARAVID	Perencar	
		90153149				
	120	430111147				
	121	42051148				
	122	42051345				
	100	40011149				
	120	48051143				
	12	42051142				
	18	90053341				
	82	\$3011147				
	100	10751133				
	100	40011118				
	12	42051137				
	100	400011194				
	100	400533.89				
	100	440111114				
	12					

2. Go to the Fieldbus Builder and click on 'Device Registration' from the menu bar to register device.

A Destruction	to size the too he	in lines it in a line in the second second				
1	R Person Test E Personal Energian Alertation	Allens Inten Cont.	Delice Tag Domest	Include 10 Including on Provide 10 (1) (1) Including on Provide 10 (1) (1) Including on Provide 10 (1) (1) Including on Provide 10 (1) (1) (1) Including on Provide 10 (1) (1) (1) (1) Including on Provide 10 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	Thinks Real	

3. Select the CKD Series actuator to register.

P10.0	to then the too have	liment Mitcherd				
	Perion Top I Corrected Institute Institute	Alliana Anton Italian Anton Anton Anton Anton Anton Anton Anton Anton	en Gerlie by Dame.	Jacobia II Printer III II Antonio III II Printer III III III III III III III III Printer III III III III III III III III III Printer III III III III III III III III III I	factor has	==
			na tatan Marina Salar Marina Salar Marina Salar			

4. You can edit the Device Tag Name as per site requirement. Node address to be input as required. Device Class to be input as basic unless the user requires the valve to work independently (away from the host DCS).

and approach strend adverse	I at at	1				
C PROPERTY OF LEASE		·	1	10.e		
+ 61 409(10)	- 12	E TTAL DALTON PTO	q Common Informets			
* E 494/104	10	Perminal Mather	Serlie Tay Dans	Florid Tag MaterillD	Termeter	01
* E 404-101		\$2051348	*			
	12	42051547				
	10	10011346				
		48051145				
	10	\$3011144				
		90011143				
	10	\$3051143				
	100	400111141				
	100	90011140				
	18	40053339				
	10	10011159				
		48051137				
	10	40011136				
	100	90001133				
	100	Autorities.				

5. Click 'File' on the menu and select download for downloading of the devices.

al at al ce
al at al te
nl re ne

6. For first download to FCS, ensure that both boxes (Enable/Disable and Block parameters) are checked. Subsequently, only the block parameters boxes need to be ticked for future downloads. Select 'OK' to proceed the next step.

Click 'Yes' to download to FCS.

	 eseratory,ca	ca) file ongo Bosor e (0) CPV e Mi e	8.6 1 200 38.0 1 200	Neurose Record	e -	12
		M M	Annual State of the State			
Part .				Tapes		

7. After downloading, you will be able to view the device in the device panel. If the device cannot be viewed, you may change the node addresses and repeat the downloading step.



(3) Analog Input

	Meaning
Al1	Torque percentage. Range 0%-100%.
Al2	Torque percentage. Range 0%-100%.
AI3	Percentage of valve position opening. Range 0%-100%. 0% indicates fully closed position, 100% indicates fully open position.
Al4	Percentage of valve position opening. Range 0%-100%. 0% indicates fully closed position, 100% indicates fully open position.

(4) Analog Input

	Meaning
AO1	Actuator opening percentage requirement. Only if DO4 adjustment enable is set to 1, the actuator will act toward the percentage value of opening demand set by AO1.

 Control logic is to be built based on user requirements. A typical cascade analog control logic is as follows: You may refer to the FF debugging manual for the function of the inputs/outputs for setting up the logic. (e.g., DO4 is to be enabled for AO to be used). The parameters setting for AI01 to AI04, AO1, DI01 to DI04, DO01 to DO04 and TB blocks are as follows:

AI01

Asianana Managa - 4040100				- 0
Add Nam Autor Dates Rel	and the second se			
1 🕱 🔍 🍤 🖻	10 x 3 3 3			
Aduat Dealer	Denice Values			
Autor	Sector 1	saids Had, Ann	A COLUMN PARTY OF	Lini fraint
Centra Tag Tenauto Venn	AD4.15K		40153	
Taken & Terror, Structure of Takings	COLUMN TAX OF A DAMA		COLUMN 1 IN LASS	
stand Cleaners Class		-	Dest Tree Time C	DOUB TO MINIT
		00000000		
	P			
d permit				
			200 C	
at Ney			D1	
COL, BLB				
Teran	. Data		Dee	
And .	55		94	
Territor	No-494-015		Chineland 1	
Tana	Nev		DN6	
ut Sw	5/101		SHEET.	
KG22				
28.4	Bat Not Sector Adjusted		Red Torchards, Torcardor	
later .	5 centres		1.7998	
a				
844	Bel GADTesia failated		Test Durithernee Tellumber	
Table .	il succes		CHANNE	· · ·
thurst the second				
Sector Inter	Inchestants Income		Charles and added	
lever her	N AND NO.		110.000	1
Terrature links	Bar Nachards Melanial		Bull Rectaulty Related	
Terrature lister	6.400x84		2.10040	
Second Rollinson	Defend		Distant	
10.04	10000		Jediment.	
214 201	100.00000		Concessor 1	-
Die Di	a second		Cite seems	
Concession in the local sectors in the local sector			100	
lanes.				
1 10 m 1	25-		191	
111 a 1000	the local	100	Crosses !	
1014 TO 1	A ADDRESS OF		Colorest .	
Contraction of Contra			1.10.000	
1000	- C		100	
and again	200		120	
an jun	100		levis .	
100			The second secon	
244	340		(Lises	

AI02

Presente Mrieger - 40 YTLH				- 0.3
A 100 100 200 to 100				
Taget Amail Device	Devue Takes		Walk Peer	
Atter	Saw Tand	1000 April -	and the second se	belved.
Farmerine Set Title	100.00		4011124	
Date & Texas , Taxana of Takana	1-10-1014-1-0110*** (avera		a latitie interim the late	
144444 - 4050/402 - 1901 -	ARE THE THE TAKE THE	H [] (H)	DEF BAR DON DON	10.000-03
THE REAL	16			
Top December			0	
lotten a			116	_
Aut Nor	1		E1	
NOD, BUT				
Surger.	Adv		DAN	12
how	0.1		05	
Percebut	Mirthird S		Energe-04	
Tenar	340		Dae	
Not Ger	6-000		6-220	
N.				
Bate	But for family totals	-	Rei Norlpech, Indepen	
Take .	\$ DADA		6.0050	- B - 1
AR				
Date	Bat Automatic Second		Bail CutOfficeria Instantel	
linker	12000	- N.	C x soorer	· ·
MALE 19				
Device lines	But the lands for lader		Cited tordeeth Income	-
Stealage States	1.0000	104	Ex Month	sile.
Territor Sea	But fire/pactic fotunted		But he lough totaged	
Terreture Value	£.00080	10	E MORE	10
Sector Schools	District		Ditenter	-
6,8345				
01x 891	100,00000	- 10	Civil Second	10%
Die D.	F SHERE	10	C # access	104
These Report	174		1 jury	
Deserved	1		D1	
NE KINE				
Dive tith	The URK OF	- A.	C 10 Secol	1.1
Poly (P)	1.0000	1	C 8 MD000	A
Units Ingles	N.		05	
Detect	2		122	
sheat_bbor				
Set.	and the second s		0.645	1.00
Dep	6.0		0.942	12
4.1	1 100 C		The second se	

AI03



AI04

Australia Manager - 4042100				
2				
	100 X 14 0			
Tage Reliad (All	have been and the second	on the local	And and the owner of the owner.	Line balance
Canada Tan Tanana Kana	ADM/100	10000000	division in the second s	
Parameter Set 788	104.02		255,450,011	
Destition for a local state	COLUMN TWO IS NOT		PORTENTIAL PARTY CANAL	
educud RESOLARD 19		409 1,100		e Caerta
the second s				
a Terration			0	
			-DEC	
at the			106	
00.03	1.51		100	
22			The	
100 C			1.84	
Sector 1	10.00.00		Charles and the	
			Case	
a fee	A COMPANY AND A		None Contraction	
2.53				
			NOT THE OWNER OF THE OWNER	
1000	Sec Net profit Net prise		Set for specific section	
S			and designed and the	
	Ber GADDenne fur press		THE COOLEMAN LINEAR	
No.	a second	- C.S.	The same	
NUT	San San and		Territoria and a second	
Sector Inte	Sac Ther (prior to future)		Die Berlande Mitadel	
Desite Title	5 48285	476	Drawn	164
Territor links	Ball New Specific Net (which		Bad NorGassia Netwood	
Treature Tatue	0.00006	15	5.55040	164
Second Rollins	Dates		CD(Inview	
0,0008				
104.005	102.00008	(78	Classes	Ma.
Die D	0.00000	174	Cit means	off a
Cres Inde	144		- Dave	-
See .	2		DF	
V7,30%3				
11/4 101	10.0000	1.8	C es anna	
4V 4 D	0.00200		Clame	- 6.11
United States	- N -		- DP	-4
Deere .	3		LI#	
Real State				
Sec	141		OW	- 12
249	62		LISN .	
	1000 C		COMPARENT.	

AO01



DI01



DI02



DI03



DI04



DO01



DO02



DO03



DO04



ΤВ



You may view the individual blocks settings by clicking the block highlighted in blue and the icon circled in red.



AI04 Input Setting

terne, making timesets	Samie [Tivillion Deg. Degram [Alarm Donnerth	on Debanded Personners
	Channel makery rissantsi	1
	Transdares Range (82_PIALE) Nige limit value	100.0
	Los Linie value	1.1
	Deployments Solt Pyshol	9
	rand digted meredalas (S. TITE)	Lisers.
	Surgers Salar Reage (USY, Stald)	355.0
	non Linis color	
	Equipmenting this symbol	<u>*</u>
	Topol Piller Time Constant (PT_PTIME) (sec)	
	179 mestion california	
	Low metall	
	ine smill value inte 1991	
	Status Sprins Others other	-
	Toosstale if Limited	
	may if indices	34
	Detectain 12 Ann mote	A4

Al03 Input Setting

Charloss Postery (Charles)	Reals Fisigns Teg Jupit Alars Connect	Los Satanded Paraketer
	Channel Paries UTARVILS	1
	Temeniaces Jacqv (NE_POALE) Righ Limit value	100-0
	hew limit value	0.9
	Regionsking Dain Systell	4
	Tapet Signal (Surveyaline (5_7518)	Bookers.
	Surper Tales Range (197_STREE) Mign Limit value	195.3
	Low Limit value	5.0
	successing min symbol	
	Input Filter Name Coursest (FF, FTIDE) [eve]	4
	1/s option (to_orea)	
	Low satisff	No
	Los maniff raise (bM_SM)	
	Martus Ophics (MERCES_COME)	
	Propagata Facts Streams	50 ·····
	Ternetele if Limited	
	BAD IF LOWING	-
	Taxertals 11 Her ands	

AO01 Input Setting



DO04



DCS screen are as follows once completed:





To check on the block parameters, enter Plant Resource Manager and click on the parameter manager.

3 ***			Sant Same	tagana Merander Mente Die Kan
	Associated (PM), Solid TPM, Periodic Hongel		heeks tag Deuks II Beeks Tag Common Commonk alam Tage 4	Konstite Berlinder (12-9-1400000,1204) Konsten Fandener fahles
Carlor tar	Division, All Sec.		Comment Book Book Series	
	Add Meen. Mathanana Mail Ind d d Ine d Add Heart Mail Add Heart Add Heart Add Heart Add Heart Meen Factor Strange Team Team Team Teams Teams Teams Teams Teams Teams Teams Teams Teams	11	Voder Calopary Hold Nodel Noder State Falls Noder State Noder Node	Negled Between St. UK Set area react states PPSL-100, 2012 1 S.m. Etc. [See]
ine .	ing stars the strength of the little	14	Same Survey	
S NOLINE	Referent Dates	° []	4411	
y Cest		10.11	AIR 2	1

Click on the update device value to read/update all the parameter block.

Tarpe	Adual Dence		10.2222	Denie Value
Action Devices Tag/Template Name Parameter Set: Ne Date & Temr., Source of Values		494/1525	494/105	
and the second se		stalling and states	Colorent could be	and the second second
Prénéral RESOURCE TROI	ADT ADT ADT ADT	A001 DI01 D	102 0103	Di64 0001
Buck Selector	AGE AGE AGE AGE	A001 D401 D	H2 [] 5H3 [0 DIGH [] 0001
Book Selector 1801	ART ART ARE ARE		H2 [] 6H0 [DIGH [] 0001
Pelantual RESOURCE TION Book Selecture 1801 Fearmer Sectors	AREAREARE	A001D01D	KD [] 5HG [_ D64 [_] 0001

There are two criteria for the FF segment:

- 1. Power: 24V
- 2. The macrocycle of each segment must be below 1000 msec.

Failure to comply with either of the above will result in communication failure. Below are the macrocycle for different numbers of input blocks.







17 Appendix A: Accessories Lists

For Ordering Wonder HC Actuator® Accessories:

Should you wish to order accessories for your Wonder HC Actuator[®], please get in touch with your local sales representative. Alternatively, you can send an email to our support team at <u>support@wonder.com.sg</u>, specifying your accessory requirements and contact details.

Customized Configurations:

If you require a customized configuration to meet your specific needs, please don't hesitate to reach out to our customer support team at <u>support@wonder.com.sg</u>. They will be happy to provide you with more information and assist you in tailoring a solution that fits your requirements.

Product Code	Product Description
A-HCCB01	Wonder HC Actuator Control Board
A-HCFB01	Wonder HC Actuator Function Board
A-HCNP01	Wonder HC Actuator Knob Plate
A-HCPB01	Wonder HC Actuator Power Board
A-HCRB01	Wonder HC Actuator Repeater Board
A-HCVP01	Wonder HC Actuator Valve Position Card
A-HCMC01	Wonder HC Actuator Remote Controller









103














109









19 Index

2

2 Line Control

32

Α

Actuator Mounting	14
Analog	33
Analog Feedback	41
Alarm Info	53
Accessories	84

В

Bus	36
Bus Baud Rate	36

С

Copyright	4
Cable Connection	15
Control Set	29
Control Mode	30
Close Valve Jiggle Area	37
Communication	64

D

Disposal/Decommisioning	12
Display Panel	20,21
Diagnosis	21
Dead Area	34

Ε

Electroc Shock Hazard	10
Explosion-Proof Housing	11
Earth/Ground Connection	15
ESD Protect Allowed	46
ESD Action Direction	46
ESD Wiring Diagram	56

F

FOUNDATION FieldBus

74

10

G

General Information

Н

Hand-wheel Sealing	15
HC-DM Linear Drive Unit	15

I

Indicator	20
Infrared Remote Controller	44

L

LCD Interface	20
Limit Position	25
Local Control	29
Low Signal Adjust	33

Μ

Modify Password	23	
Motor Jiggle Counter	37	
Maintenance	63	
MODBUS Setting	64	

0

Operation Guide Open Limit Set	22	
	26	
Open Over Torque	27	
Open Valve Jiggle Area	37	

Ρ

```
Password
```

22

R

Rising Stem Valve	14
Remote Control	31
Rating Torque/Rating Current/	
Stall Current Setting	52
Remote Analog Signals Control	59
Remote Analog Signals Control	
and Switch Control	60
Remote MODBUS Signals	
Control and Switch Control	61

S

C - +++' T I	h
Setting lool	3
Safety Precautions	5
Service Request/Repair	12
Signal Loss Action	35
Stall Current	52

Т

Trademark Technical Installation Torque Protect	4 14 26
v	
Valve with Gearbox	15
w	
Wiring Diagram	55



© 2024 WONDER® ENGINEERING TECHNOLOGIES PTE LTD. ALL RIGHT RESERVED.

The information contained herein shall not be copied, transferred, conveyed, or display in any manner that would violate its proprietary nature without the express written permission of Wonder[®] Engineering Technologies Pte Ltd.

